

---

MODEL **3565**

Digital Ohm Meter

Instruction Manual

---

I-01261

# Contents

1.	Preface .....	3
1.1	•Preparations prior to use.....	3
1.1.1	Inspection .....	3
1.1.2	Storage.....	3
1.2	•Confirmations prior to use.....	3
1.2.1	Power supply .....	3
1.2.2	Power supply cable.....	3
1.2.3	Replacement of fuse .....	4
2.	Name of parts and functions .....	5
2.1	•Front panel .....	5
2.2	•Rear panel .....	7
3.	Operation .....	8
3.1	•Power supply.....	8
3.2	•Connection of measuring terminals.....	8
3.3	•Connection of temperature sensor.....	8
3.4	•Key lock.....	9
3.5	•Change-over of measuring range .....	9
3.6	•Zero adjustment.....	10
3.6.1	Key operation.....	10
3.6.2	Remote operation .....	10
3.7	•Selection of sampling rate .....	10
3.8	•Comparator operation .....	11
3.8.1	Conditions for comparison.....	11
3.8.2	Comparator output .....	11
3.8.3	Setting method.....	12
3.8.4	Display mode of range lamps.....	13
3.9	•Buzzer.....	14
3.9.1	Setting method.....	14
3.10	•Manual mode.....	15
3.11	•Memory mode .....	15
3.11.1	Selection of memory.....	15
3.11.2	Setting of memory .....	16
3.12	•Detection of broken line & self-check .....	18
3.12.1	Operation .....	18
4.	Remote control .....	19
4.1	•Remote connector .....	19
4.1.1	Pin operation.....	19
4.1.2	Remote operation of memory mode .....	20
4.1.3	Timing chart of remote control.....	21
4.2	•Remote control (input & output terminal block).....	22
5.	Setting Method .....	23
5.1	•Resistance measurement .....	23
5.2	•Temperature measurement.....	23
5.3	•Temperature compensation function .....	24
5.3.1	Setting of standard temperature and temperature coefficient.....	25
5.4	•Temperature conversion function.....	26
5.5	•Ratio display function .....	28
5.5.1	Setting of standard value and deviation .....	29
5.6	•Character display.....	30
6.	Panel mount use.....	31
6.1	•Assembly for mounting.....	31
6.2	•External dimensions when fitting panel mount brackets .....	31
7.	Calibration .....	32
7.1	•Materials to prepare .....	32
7.2	•Calibration method .....	32
7.2.1	Calibration of resistance measuring range .....	32
7.2.2	Calibration of temperature measuring range .....	33
8.	Specifications .....	34
8.1	•Model name.....	34
8.2	•Measuring range & accuracy .....	34
8.3	•General specifications .....	35
8.4	•Table of initial set values (at delivery from factory).....	36
8.5	•External dimensions.....	36
8.6	•Interface (option).....	36

## 1. Preface

---

We thank you for your purchase of our MODEL 3565. For safety and proper use of this product, please carefully read this instruction manual before the initial operation. Model 3565 is a fast speed type Digital Ohm Meter of maximum sampling rate 100 times/sec. and response speed 50ms. For the resistance measurement, the meter is provided with a wide range from 300m $\Omega$  to 300k $\Omega$  and it can perform high precision measurement of high resolution 10  $\mu$   $\Omega$ . Also provided as standard are the temperature compensation function, ratio display function and temperature conversion function which allows to measure the risen temperature of coil resistance. With a comparator memory function of 30 patterns, it is also possible to preset the test conditions for plural numbers of test samples. Six different types of optional data output interfaces such as GP-IB, RS-232C etc. are provided for the meter to serve a wide range of applications from stand alone use to systematized operation.

### CAUTION

- **To avoid break-down, malfunction or deterioration of life time, do not use this product in such places where:**
  - ◆ **exposed to rain, water drops or direct sunlight.**
  - ◆ **high temperature or humidity, heavy dust or corrosive gas.**
  - ◆ **affected by external noise, radio waves or static electricity.**
  - ◆ **where there is constant vibration or shock.**
- **Do not dismantle or modify this product.**

## 1.1 ●Preparations prior to use

---

### 1.1.1 Inspection

When the meter is delivered, please check whether it conforms to the ordered specifications and has not been damaged in transit. If any damage or inconvenience in operation is found, please inform us of the model name and serial number of the product.

### 1.1.2 Storage

When the meter is not in use for long time, store it in the place of low humidity where the meter is not exposed to the direct sunlight.

## 1.2 ●Confirmations prior to use

---

### 1.2.1 Power supply

Use this meter with the power supply voltage within the range 90V~250VAC, frequency 50~60Hz. Also, ensure that the power switch is turned OFF when connecting the power supply cord.

### 1.2.2 Power supply cable


Power supply cable plug attached to this meter is for the 100VAC. When the meter is used with 200VAC, replace the plug with appropriate one for 200VAC use.

Make a connection of power supply cable to the power supply connector on the rear panel of the meter.

The plug has 3 pins and the round shaped pin at the center is for grounding. When the connection is made to a plug receptacle by use of the adaptor attached to the plug, ensure to connect the earth lead coming out from the adaptor to the external earth terminal for grounding.


### 1.2.3 Replacement of fuse

A power supply fuse 250V/2A is mounted when the meter is delivered from factory. The fuse socket of this meter is common with the connector for input of power source line. Before connecting the power cord, take off a cap of fuse socket and confirm the rated value of fuse. Two fuses including a spare are stored inside the cap. The fuse at outer side can be removed by pushing it toward right or left, and another fuse at inner side pushing downward.



## 2. Name of parts and functions

### 2.1 ● Front panel




- ① Measuring terminals    SENSE Hi : +side terminal of voltage input.  
                                  SENSE Lo : -side terminal of voltage input.  
                                  SOURCE Hi : +side terminal of current output.  
                                  SOURCE Lo : -side terminal of current output.
- ② **[OHM]** key                    Key to select resistance measurement. OHM lamp is lit up when selected.  
     (0 ADJ)                    (ON/OFF key for zero adjustment. 0 ADJ lamp is lit up during operation.)
- ③ **[TEMP]** key                   Key to select temperature measurement. TEMP lamp is lit up when selected.  
     (RATE)                    (Key to select a sampling rate.)
- ④ **[T.C.]** key                   Key to select temperature compensation function. T.C lamp is lit up when  
     (SET)                      selected.  
                                  (Used for various setting.)
- ⑤ **[RATIO]** key                   Key to select ratio display function. RATIO lamp is list up when selected.  
     (MAN'L/MEM)            (Key to switch over manual-mode/memory-mode. MAN'L lamp is lit up  
                                  with manual-mode.)
- ⑥ **[TE]** key                      Key to select temperature conversion function. TE lamp is lit up when  
     (ONLINE)                   selected.  
                                  (On-line key for GP-IB, RS-485, RS-232C.)
- ⑦ **[SHIFT]** key                   Key to effectuate the blue key. SHIFT lamp is lit up when effectuated.  
     (LOCK)                      When the blue key is pressed with the lamp in lighting, the effectuation is  
                                  released.  
                                  (Switch to prohibit switch operation on the front panel. When it is pressed  
                                  continuously for 3 seconds or more, prohibition or release can be done.  
                                  During the prohibition, LOCK lamp is lit up.)
- ⑧ **[RANGE]** key                   Key to select range 300mΩ ~300kΩ or AUTO range.  
     (BUZZER)                   (Key to select buzzer operation and volume setting.)
- ⑨ **[SEL]** key                      Used for various setting.  
     COMP SET
- ⑩ **[▶]** key                        Used for various setting.
- ⑪ **[▲]** key                        Used for various setting.

---

⑫ 0 ADJ Lamp LOCK Lamp MAN'L Lamp ONLINE Lamp SHIFT Lamp	Lit up at zero adjustment operation. Lit up at key lock. Lit up in manual mode and turned off in memory mode. Lit up when remote controlled. Linked with SHIFT key.
⑬ TEMP Lamp OHM Lamp T.C Lamp RATIO Lamp TE Lamp	Lit up in temperature measurement. Lit up in resistance measurement. Lit up in temperature compensation function. Lit up in ratio display function. Lit up in temperature conversion function.
⑭ F Lamp M Lamp S Lamp	Lit up at sampling rate 100 times/sec. Lit up at sampling rate 20 times/sec. Lit up at sampling rate 4 times/sec.
⑮ HI Lamp GO Lamp LO Lamp	Red LED is lit up when the measured value is higher than high limit. Green LED is lit up with good judgement. Red LED is lit up when the measured value is lower than low limit.
⑯ Unit Lamp	Lamp of the unit in measurement is lit up.
⑰ Range Lamp AUTO Lamp	Lamp of the measuring range is lit up. Lit up when the auto range is selected.
⑱ Display Window	Measured value and characters are displayed.
⑲ NO Display	Memory No. of memory mode is displayed.
⑳ HI SET Display Window REF Display Window °C Display Window	High limit of comparator is displayed. Content of setting is displayed at buzzer setting. Standard value in ratio display is displayed. Standard temperature in setting of temperature compensation is displayed.
㉑ LO SET Display Window ± Δ% Display Window ppm Display Window	Low limit of comparator is displayed. Volume is displayed at buzzer setting. Deviation in ratio display is displayed. Temperature coefficient is displayed at setting of temperature compensation.


※ Keys in “blue characters” are effective during the SHIFT lamp is lighting.

## 2.2 ● Rear panel



- ②③ Rear measuring terminals  
 SENSE Hi : Common with the measuring terminal (SENSE Hi) on the front panel.  
 SENSE Lo : Common with the measuring terminal (SENSE Lo) on the front panel.  
 SOURCE Hi : Common with the measuring terminal (SOURCE Hi) on the front panel.  
 SOURCE Lo : Common with the measuring terminal (SOURCE Lo) on the front panel.
- ②④ Power supply connector  
 Connect the attached power supply cord to this connector. Ensure to apply the power source voltage and frequency with the specified range. Fuse of 250V 2A is to be used.
- ②⑤ Power supply switch  
 ON/OFF switch for power supply.
- ②⑥ REMOTE connector  
 Connector for remote control.
- ②⑦ Input, output terminal blocks  
 Terminals for input of hold and input, and output of comparator.


Terminal screws: M3  
 Fastening torque: 0.6~1.0N・m  
 Crimp terminal: As shown on the right.



- ②⑧ Pt100 $\Omega$  connector  
 Connector for connection of 3-wire system Pt100 $\Omega$  resistance bulb.
- ②⑨ Inlet for interface board  
 Section to fit an optional interface board.

### 3. Operation

#### 3.1 ●Power supply




After confirming that the power supply switch on the rear panel is OFF, connect the power supply plug to the plug receptacle and turn ON the power supply switch. Although the meter will immediately be in operating status, it is recommended to have a pre-heating time for 30 minutes or more. The meter is provided with the function to retain the parameters, so it memories the status of the followings even after the meter is switched OFF.

- (1) Measuring function and range.
- (2) Set values of comparator (30 program memories).
- (3) Standard temperature and temperature coefficient of temperature compensation function.
- (4) Standard resistance value of ratio display function.
- (5) Status of key lock.
- (6) Status of buzzer.
- (7) Status of zero adjustment.

#### 3.2 ●Connection of measuring terminals


Make a connection to the measuring terminals on the front panel (or rear panel) as **Fig.3.2.1** shows.



**Note:** Penetration of disturbing noise to the measuring terminals may cause instability or display or auto range operation. Prevent the noise by connecting with shield wire the shield side to SOURCE Lo.

**Fig.3.2.1**



Please carry out plugging of the Kelvin clips (banana plug side) and the resistance meter as follows.



**Fig.3.2.2** Connection of optional Kelvin clip (MODEL 5811-21B).

#### 3.3 ●Connection of temperature sensor

When the functions of temperature measurement, temperature compensation or temperature conversion is used, connect an optional Pt100  $\Omega$  sensor (MODEL 5803-11) to the Pt100  $\Omega$  connector on the rear panel.






---

### 3.4 ●Key lock

---

This is the switch to prohibit the key operation on the front panel so that the measuring condition can not be carelessly altered.

LOCK lamp is lit up during the key locking. When required to operate other switch, do it after releasing the key lock.



#### To make key lock

Press **[SHIFT]** (LOCK) key for 3 sec. or more when LOCK lamp is turned off.

#### To release key lock

Press **[SHIFT]** (LOCK) key for 3 sec. or more when LOCK lamp is lighting

---

### 3.5 ●Change-over of measuring range

---

Select a measuring range (auto range or manual range) of resistance measurement.

This operation is disabled in memory mode and when the status is ONLINE or HOLD.

#### (1) Auto range

- The measuring range automatically steps up when the display value is 35000 (3500) or higher and steps down when the display value is less than 3000 (300).
- AUTO lamp and the lamp of the range automatically detected are lit up.

**Note:** Figures in the brackets ( ) are at F sampling.

#### Selection of AUTO range


When the **[RANGE]** key is pressed at the 300k $\Omega$  range, AUTO lamp is lit up and the meter enters the auto ranging.

#### (2) Manual range

- The range is fixed at 300m $\Omega$ ~300k $\Omega$ .
- The lamp of the selected range is lit up.

#### Change-over of range

Every time the **[RANGE]** key is pressed, the range lamp moves. Select the range intended.



### 3.6 ●Zero adjustment

This is the function to suppress the resistance of tools and so on in resistance measurement. The value currently measured is memorized as zero set value into the non-volatile memory and afterwards, the value from which the zero set value is suppressed is displayed.


$$\boxed{\text{Display value}} = \boxed{\text{Measured value}} - \boxed{\text{Zero set value}}$$

- This function is enabled in manual mode and memory mode of the resistance measurement, temperature compensation function, temperature conversion function and ratio display function.
- Zero set value is effective in all ranges.
- In case that the zero adjustment is made in the higher range, it may over-range in the lower range.
- Remote control is possible for this function.
- Remote control through the interface GP-IB, RS-232C or RS-485 is also possible.

**Note:**

- This function can not be operated during the temperature measurement and the hold.
- Zero adjustment is not released even if the memory is changed in memory mode.

#### 3.6.1 Key operation



- ① Press **[SHIFT]** key when 0 ADJ lamp is turned off. SHIFT lamp is lit up.
- ② Press (0 ADJ) key. 0 ADJ lamp is lit up. Zero adjustment becomes operating status.
- ③ To release the zero adjustment, do the operation ① and ② during the zero adjustment.

#### 3.6.2 Remote operation

As long as the 0 ADJ pin of REMOTE connector on the rear panel is made ON, the 0 ADJ lamp is lit up and the zero adjustment function becomes operable.


When the pin is turned OFF, the function is released.

**Note:** Zero adjustment work set up with the key operation is released by making this pin OFF.

### 3.7 ●Selection of sampling rate

Make a choice of sampling rate with key operation on the front panel.

- Remote control through the interface GP-IB, RS-232C or RS-485 is possible.
- Selection is not possible during the hold function.



- ① Press **[SHIFT]**. SHIFT lamp is lit up.
- ② Press (RATE) key. Sampling rate changes.
- ③ Repeat ① and ②, and the rate changes in the order of:

S→M→F→S

S lighting : 4 times/sec.  
M lighting : 20 times/sec.  
F lighting : 100 times/sec.

**Note:** When the sampling rate is F, 100 times/sec., noise suppression for the power source frequency noises penetrated in the input does not function.

---

### 3.8 ● Comparator operation

---

This is a digital comparator to make a comparison between displayed value and high or low limit value. 30 pairs of high and low limit value (No.1~No.30) can be memorized.

- Memory can be selected by REMOTE connector.
- Selection of memory can also be done through the interface GP-IB, RS-232C or RS-485.

**Note:**

- During the setting of high or low limit and recalling of the memory, the sampling is stopped and the comparator output is held.
- Comparator does not operate at the temperature display.

#### 3.8.1 Conditions for comparison

Display value $\geq$ High limit value (HI SET)	HI output
High limit (HI SET) $>$ Display value $>$ Low limit (LO SET)	GO output
Display value $\leq$ Low limit (LO SET)	LO output

**Note:** Comparator makes comparison with absolute value.  
As an example, in case that the high limit is set to 100.00m $\Omega$ ,  
HI is output when 10.00 $\Omega$  is displayed in the 300 $\Omega$  range.

#### 3.8.2 Comparator output

Open collector or relay contact output is output through the input/output terminals on the rear panel. (refer to the article 4.2)

Display : HI and LO : Red  
          GO : Green

### 3.8.3 Setting method

Comparator can not be set during the ONLINE, remote control through BCD data output interface and hold.

Adjustable range    High limit : -19999~35000    **Note:** The unit and decimal point are set by RANGE key.  
                              Low limit : -19999~35000

This article explains the method how to set the high and low limit values for the resistance value in manual mode.

- Refer to the article 5.5 for the setting of ratio display function.
- Refer to the article 3.11.2 for the setting in memory mode.
- When no key operation has been done for about 5 minutes during the setting, the meter returns to measurement mode.

#### Change over to manual mode


- ① (refer to the article 3.10)

#### Selection of function

- ② Change to resistance measurement with [OHM] or [T.C] key.


#### Setting of high limit

- ③ Press [SEL] key.  
 The highest digit of HI SET display blinks.  
 Set a numeral with [▶] and [▲] keys.  
 The digit selected with [▶] key blinks.



#### Setting of low limit

- ④ Press [SEL] key.  
 The highest digit of LO SET display blinks.  
 Set a numeral with [▶] and [▲] keys.  
 The digit selected with [▶] key blinks.



#### Setting of comparator range


- ⑤ Select with [RANGE] key.  
 The selected range lamp blinks.

Example shows HI SET from 02.017Ω to 200.00Ω.  
 LO SET from 00.000Ω to 100.00Ω.

#### Finish of setting

- ⑥ Press [SEL] key.

- Note 1:** When returned to the measurement mode and measuring range and comparator range are different with each other, the range lamp of comparator range blinks.
- Note 2:** When the H or L setting is out of adjustable range, blinking Err is displayed for the setting parameter in question for a while and returns to the setting ③ or ④.



---

### 3.8.4 Display mode of range lamps

The model 3565 is designed to display both selected measuring range and comparator set value. When the comparator set value is different from the selected measuring range, the comparator set value is displayed in blinking.

Examples: 1. When the measuring range and comparator set value are different.

Measuring range	3k $\Omega$ range is selected.
Comparator set value	HIGH 300.00 $\Omega$ LOW 100.00 $\Omega$ (range is 300 $\Omega$ )
Range display	3k $\Omega$ steadily lighting 300 $\Omega$ blinking

2. When the measuring range and comparator set value are same.

Measuring range	300 $\Omega$ range is selected.
Comparator set value	HIGH 300.00 $\Omega$ LOW 100.00 $\Omega$ (range is 300 $\Omega$ )
Range display	300 $\Omega$ steadily lighting

3. In AUTO range.


Measuring range	AUTO 3k $\Omega$ range is selected. (selected by input resistance)
Comparator set value	HIGH 300.00 $\Omega$ LOW 100.00 $\Omega$ (range is 300 $\Omega$ )
Range display	AUTO 3k $\Omega$ steadily lighting 300 $\Omega$ blinking

## 3.9 ●Buzzer

Setting of buzzer is done with (BUZZ) key on the front panel.


- During the setting of buzzer, the sampling is stopped and the comparator output is held.
- Setting is disabled during ONLINE and hold.
- When no key operation has been done for about 5 minutes during the setting, the meter returns to measurement mode.

### 3.9.1 Setting method



#### Setting of buzzer


- ① Press **SHIFT** key.  
SHIFT lamp blinks.
- ② Press **(BUZZER)** key.  
HI SET display blinks.



#### Selection of buzzer operation

- ③ Select with **▲** key.  
HI SET display blinks.

Display	Operation
Good	Buzzer sounds at GO output.
HI nG	Buzzer sounds at HI output.
Lo nG	Buzzer sounds at LO output.
nG	Buzzer sounds at HI and LO output.
oFF	Buzzer is turned OFF.



#### Adjustment of sound volume

- ④ Press **SEL** key.  
Buzzer sounds.  
Adjust with **▲** key to a proper sound volume.  
The volume is adjustable in 10 steps.

Example shows the setting from buzzer OFF to GOOD, volume from 10 to 5.

#### Finish

- ⑥ Press **SEL** key.


### 3.10 ● Manual mode

In this mode, the temperature measurement, temperature conversion function etc. can be operated.

- It is not possible to change over to manual mode when the ONLINE is lit up by remote operation.

#### Operating procedures

- Make a change of manual mode / memory mode with SHIFT key and (MAN'L/MEM) keys.  
During the manual mode, MAN'L lamp is lit up but the memory No. is not.




### 3.11 ● Memory mode

In this mode, the measurement with either one of 30 stored memories is possible.  
The sampling rate is common in this case.

#### 3.11.1 Selection of memory

- By means of operation on the front panel



#### To enter memory mode

- ① Press **SHIFT** key.  
SHIFT lamp is lit up.
- ② Press (MAN'L/MEM) key.  
Memory No. is displayed.

#### To recall memory

- ③ Press **SEL** key.  
Select a memory No. and call it.

#### To finish memory mode

- ① Press **SHIFT** key.  
SHIFT lamp is lit up.
- ② Press (MAN'L/MEM) key.

- By means of remote operation

Refer to Remote Connector (article 4.1).

### 3.11.2 Setting of memory


Set the meter to memory mode. When the memory mode is engaged by MEM signal through REMOTE connector, the setting of memory is not allowed.

The parameters which can be memorized into the memory are following three:

- Function (temperature measurement and temperature conversion function can not be set).
- Comparator (high and low limit, REF of ratio display function,  $\pm \Delta \%$ )
- Range of resistance measurement.

**Note:**

- Compensation temperature  $^{\circ}\text{C}$  of temperature compensation function and temperature coefficient ppm of resistance can not be set. The values set in the manual mode remain as common value for the respective memory.
- Setting is not allowed in the ONLINE status.
- Setting is not allowed during the hold.
- During the setting, the sampling is stopped and the comparator output is held.
- When no key operation has been done for about 5 minutes during the setting, the meter returns to measurement mode.




Enter memory mode

- ① (Refer to article 3.11.1)

To set memory


- ② Press **SHIFT** key.  
SHIFT lamp is lit up.  
Press (SET) key.  
SEF blinks on the display.



Selection of memory No.

- ③ Memory No. display blinks.  
Select a memory No. with **▲** key.

Example shows the selection of memory No.15 when displayed is No.10.



Setting of function

It can be set when the memory No. is blinking.


- ④ Select **OHM**, **T.C** or **RATIO** with respective key.

Setting of measuring range

It can be set when the memory No. is blinking.

- ⑤ Select with **RANGE** key.






#### Setting of comparator, ratio display

⑥ Press **[SEL]** key.

HI SET display and the highest digit of REF display blink.


- When OHM or T.C is selected at ④, set a high limit of comparator. (Refer to the article 3.8.3)
- When RATIO is selected at ④, set a standard value of ratio display function. (Refer to the article 5.5.1)



⑦ Press **[SEL]** key.

LO SET display and the highest digit of  $\pm \Delta\%$  display blink.

- When OHM or T.C is selected at ④, set a low limit of comparator. (Refer to the article 3.8.3)
- When RATIO is selected at ④, set a deviation of ratio display function. (Refer to the article 5.5.1)



#### Finish

⑧ Press **[SEL]** key.

It can be finished with the memory No. display in blinking status.

⑨ Press **[SHIFT]** key.

SHIFT lamp blinks.  
Press (SET) key.


### 3.12 ● Detection of broken line & self-check

Checking for broken line of the measuring leads of SOURCE and SENSE, and a diagnosis of fault in voltage regulator circuit can be done in this mode.

In case that an error is detected, CC ERR output is turned ON.

CC ERR output is also turned ON in such cases as the current does not flow due to open-circuit of SOURCE terminal and so on.


**Note:** During the operation, the sampling is stopped and the comparator output is held.



#### 3.12.1 Operation


##### Preparation

- ① Connect the measuring leads to the meter.
- ② Connect the object to be measured to another end of measuring leads or make short-circuit of them.



##### Start of broken line detection and self-check

- ③ Turn ON the SW input on REMOTE connector.  
(Refer to the article 4.1.1)  
rS CC is displayed on the display window.



##### Result of broken line detection and self-check

- ④ When no error is detected:  
rSEnd is displayed.
- ⑤ When an error is detected, the symbols are displayed:  
ErrSo : Broken line of SOURCE side lead wire.  
ErrSE : Broken line of SENSE side lead wire.  
Check the condition of lead wires.  
  
Errin : Abnormality in voltage regulation circuit.  
Breakdown of internal circuit is also considered.


##### Finish of broken line detection and self-check

- ⑥ Turn OFF the SW input on REMOTE connector.


## 4. Remote control

### 4.1 Remote connector

#### 4.1.1 Pin operation



Input circuit ( "L" =1.5V or less "H" =3.5~5V  $I_{in} \leq -1mA$  )



(Dsub15pin)

Pin No.	Signal	Function
1	0 ADJ input	Zero adjustment is done by making this signal ON. (Refer to the article 3.6)
2	NC	Vacant pin.
3	MEM input	Memory mode is selected by turning this signal ON.
4	TRIG input	One shot sampling is done and the judgement result is output by making this signal ON during the hold, Min. ON time: 5 ms
5	SW input	Broken line detection & self-check is started by making this signal ON.
6	E0C output	Transistor output is turned ON when finished AD conversion.
7	CC ERR output	Transistor output is made ON when the current does not flow due to open circuit of SOURCE terminal, the error is detected in broken line detection & self-check and so on.
9 10 11 12 13	M-SEL0 M-SEL1 M-SEL2 M-SEL3 M-SEL4	Input a memory No. and recall memory in memory mode.
14	HOLD input	Same action as HOLD on input/output terminals is made. They are internally connected as common.
8, 15	COM	Common for input and output.

#### 4.1.2 Remote operation of memory mode

① As long as MEM signal is kept ON, the mode is memory mode.

- When moved to the memory mode, ONLINE lamp is lit up.
- Memory No. being selected is displayed.

**Note:** In case that the code other than specified is selected, it is not allowed to enter the memory mode. Make an input of the code 1~30.

② Make an input of code of the memory No. and recall the memory.

Memory code table

Signal	Weight	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
M-SEL0	1		○		○		○		○		○		○		○		○
M-SEL1	2			○	○			○	○			○	○			○	○
M-SEL2	4					○	○	○	○					○	○	○	○
M-SEL3	8									○	○	○	○	○	○	○	○
M-SEL4	16																

Signal	Weight	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
M-SEL0	1		○		○		○		○		○		○		○		○
M-SEL1	2			○	○			○	○			○	○			○	○
M-SEL2	4					○	○	○	○					○	○	○	○
M-SEL3	8									○	○	○	○	○	○	○	○
M-SEL4	16	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

○ : Makes ON

Blank : Turns OFF


0, 31 : No change

② Turn OFF MEM signal.

- Moving to the manual mode, ONLINE lamp is turned OFF.
- Finishes the memory mode.

### 4.1.3 Timing chart of remote control


#### (1) Measurement action




$$T_{sh} = \text{Sampling rate} + 3\text{ms}$$

$$\text{Sampling rate: } F = 10\text{ms} \quad M = 50\text{ms} \quad S = 250\text{ms}$$

#### (2) Zero adjustment



#### (3) Change-over of memory (change-over of memory/manual is the same)




$$T_s = \text{Sampling rate}$$


## 4.2 Remote control (input & output terminal block)

### Terminal arrangement

#### Open collector output



#### Relay contact output



#### (1) HOLD terminal (hold)

By short-circuiting the HOLD terminal on the rear panel to COM terminal, the display value, comparator output and BCD data output are held. During the hold operation, operation of all the switches is disabled.

#### (2) RST terminal (reset)

By short-circuiting the RST terminal on the rear panel to COM terminal, the comparator output is reset and the comparator display is turned OFF.

##### ○ One shot sampling hold action

With the condition that HOLD is short-circuited, one shot sampling hold can be done by switching ON/OFF the RST. Do one shot sampling hold with the manual range.

In case of auto range, it may cause an error.


#### (3) Comparator output

Open collector output : HI, GO, LO, one for each, sink type  
30V 30mA Max.

Relay contact output : HI, GO, LO, one "a" contact for each  
250VAC 1A resistive load

## 5. Setting Method


### 5.1 ● Resistance measurement



#### Operating procedures

- ① Set to manual mode (Refer to the article 3.10).
  - ② Press **OHM** key.  
OHM lamp is lit up.
  - ③ Make various setting depending upon requirement.  
Measuring range (Refer to the article 3.5)  
Zero adjustment (Refer to the article 3.6)  
Sampling rate (Refer to the article 3.7)  
Comparator (Refer to the article 3.8.3)
  - ④ Start measurement.
- Remote control by means of GP-IB, BCD data output, RS-232C or RS-485 interface is possible.
  - Operation is disabled during the memory mode, on-line and holding

### 5.2 ● Temperature measurement



#### Operating procedures

- ① Connect a temperature sensor (Pt100  $\Omega$ ) to the rear panel connector.
  - ② Set to manual mode (Refer to the article 3.10).
  - ③ Press **TEMP** key.  
TEMP lamp is lit up.
  - ④ Starts measurement.
- Remote control by means of GP-IB, BCD data output, RS-232C or RS-485 interface is possible.
  - Operation is disabled during the memory mode, on-line and holding
  - Comparator does not operate.
  - Setting of sampling rate is not possible.

### 5.3 ● Temperature compensation function

This function allows to convert the resistance of conductor, which is measured together with the ambient temperature, to the resistance value referred to the standard temperature and to display it. Standard temperature is adjustable in the range 0~149.9°C, and the temperature coefficient in the range 1000~4999ppm. In case of copper wire, for example, the standard temperature is set to 20°C and the temperature coefficient at 3930ppm.

The ambient temperature is measured by connecting a Pt100 Ω sensor.


Calculation formula

$$R_T = \frac{R_t}{1 + \alpha_T \times 10^{-6} (t - T)} \quad (\Omega)$$

- t : Ambient temperature (range 0~40 °C).  
 R<sub>T</sub> : Compensation resistance (Ω).  
 R<sub>t</sub> : Resistance value (Ω) at ambient temperature t °C.  
 α<sub>T</sub> : Temperature coefficient (adjustable range 1000~4999ppm).  
 T : Standard temperature (adjustable range 0.0~149.9°C).

Accuracy : Add ±0.3% of rdg. to the accuracy of resistance measurement.

#### Operating procedures



- ① Connect a temperature sensor (Pt100 Ω) to the rear panel connector.
- ② Set to manual mode (Refer to the article 3.10).
- ③ Press T.C key.  
T.C lamp is lit up.

**Note:** When the temperature sensor is not connected or is over range due to broken line etc., Err-1 is displayed on the display and the comparator output HI or LO is simultaneously output.

- ④ Make various setting depending upon requirement.  
 Measuring range (Refer to the article 3.5)  
 Zero adjustment (Refer to the article 3.6)  
 Sampling rate (Refer to the article 3.7)  
 Comparator (Refer to the article 3.8.3)
- ⑤ Start measurement.
- ⑥ To release the temperature compensation function, select other other function.



### 5.3.1 Setting of standard temperature and temperature coefficient


- During the setting, the sampling is stopped and the comparator output is held.

#### Move to temperature compensation function

- Refer to the operating procedures.

#### Setting of standard temperature


- Press **SHIFT** key.  
SHIFT lamp is lit up.  
Press **(SET)** key.  
The highest digit of °C display window blinks.  
Set standard value with **▶** and **▲** keys.  
The digit selected with **▶** key blinks.



Adjustable range: 0.0~149.9°C

#### Setting of temperature coefficient

- Press **SEL** key.  
The highest digit of ppm display window blinks.  
Set a numeral with **▶** and **▲** keys.  
The digit selected with **▶** key blinks.



Example the standard temperature is set to 20°C and the temperature coefficient at 3930ppm.

Adjustable range: 1000~4999ppm

#### Finish

- Press **SEL** key.

**Note:** When the setting is out of adjustable range, blinking Err is displayed for the setting parameter in question for a while and returns to the setting ③ or ④.

## 5.4 ● Temperature conversion function (Measurement of risen temperature of copper coil)

By measuring the resistance value of conductor coil at its initial condition and after its conductance test, the temperature of the conductor coil risen due to conductance is measured.

- Comparator can not be set.

Display range of risen temperature: 0~±199.9°C

Calculation formula

$$T.E = \frac{R_2}{R_1} (235 + T_1) - 235 - T_2(^{\circ}\text{C})$$

- T.E : Risen temperature value (°C).  
 T<sub>1</sub> : Ambient temperature at the start of temperature test (range 0~40 °C).  
 T<sub>2</sub> : Ambient temperature at the end of test (range 0~40 °C).  
 R<sub>1</sub> : Resistance value (Ω) of coil at temperature T<sub>1</sub>.  
 R<sub>2</sub> : Resistance value (Ω) of coil at temperature T<sub>2</sub>.

### Operating procedures

#### Measuring mode of T<sub>1</sub>, R<sub>1</sub>

- ① Set to manual mode (Refer to the article 3.10).

- ② Press **[T.E]** key.

OHM lamp and TE lamp are lit up.

**Note:** When the temperature sensor is not connected or is over range due to broken line etc., Err-1 is displayed on the display and the comparator output HI or LO is simultaneously output.


- ③ Make various setting depending upon requirement.

Measuring range (Refer to the article 3.5)

Zero adjustment (Refer to the article 3.6)

Sampling rate (Refer to the article 3.7)

- ④ Connect a test sample with Kelvin clip.




#### Memory of T<sub>1</sub>, R<sub>1</sub>

- ⑤ Press **[T.E]** key.

OHM lamp is turned off and TE lamp is lit up.

Memorizes T<sub>1</sub>, R<sub>1</sub> and moves to measurement of T<sub>2</sub>, R<sub>2</sub>.

Display window shows the risen temperature.



#### Conductance test of test sample

- ⑥ Remove the Kelvin clip from the test sample.

Perform the conductance test etc. of the test sample.


- When the power of the meter is turned off, it starts from ⑤.
- During the risen temperature is displayed, it is not allowed to switch over to other function.


#### Measurement of risen temperature

- ⑦ After completing the conductance test, connect the test sample with Kelvin clip and measure T<sub>2</sub>, R<sub>2</sub>.

Temperature risen due to the test is displayed.

**Note:** When R<sub>1</sub> is 0 Ω (when made to 0 by zero adjustment), blinking Err-2 is displayed on the display and the comparator output HI or LO is simultaneously output.





Finish

- ⑧ Press **T.E** key.  
rE is displayed.  
(If T.E key is pressed again, it returns to ⑦.)  
Select other function.

## 5.5 ● Ratio display function

The measured resistance  $R_x$  is compared to the standard resistance value  $R_s$  and its ratio is displayed in percentage.

Also, a comparative judgement is possible with deviation ( $\pm \Delta\%$ )

Display range : 0.0~199.9%

Adjustable range of deviation value ( $\pm \Delta\%$ ) : 0.0~ $\pm 100.0\%$

Calculation formula:

$$X = \frac{R_x}{R_s} \times 100\%$$


$$\Delta = \left[ \frac{R_x}{R_s} - 1 \right] \times 100\%$$

X : Ratio (%)

$R_s$  : Standard resistance ( $\Omega$ )

$R_x$  : Measured resistance ( $\Omega$ )

$\Delta$  : Deviation (%)



### Operating procedures

- ① Set to manual mode.  
(Refer to the article 3.10)
- ② Select either function with **[OHM]**,  
or **[T.C]** key.
- ③ Press **[RATIO]** key.  
RATIO lamp is lit up.
- ④ Make various setting depending upon necessity.  
Measuring range (Refer to the article 3.5)  
Zero adjustment (Refer to the article 3.6)  
Sampling rate (Refer to the article 3.7)
- ⑤ Start measurement.

### Finish

- ⑥ Select other function.
- Remote control by GP-IB or BDC data output interface is possible.
- In case of ratio display of resistance measurement, press **[RATIO]** key following the **[OHM]** key.  
OHM and RATIO lamps are lit up.
- In case of ratio display of temperature compensation, press **[RATIO]** key following the **[T.C]** key.  
T.C and RATIO lamps are lit up.

Display = ((measured resistance)  $\times$   
(temperature compensation calculation))  
 $\times$  Ratio calculation

### 5.5.1 Setting of standard value and deviation


#### Move to ratio display function

- ① Refer to the operating procedures.

#### Setting of standard temperature

- ② Press **[SEL]** key.  
The highest digit of REF display window blinks.  
Set a numeral with **[▶]** and **[▲]** keys.  
The digit selected with **[▶]** key blinks.
- ③ Select the range of standard value with **[RANGE]** key.


Adjustable range: -19999~35000



#### Setting of deviation

- ④ Press **[SEL]** key.  
The highest digit of  $\pm \Delta\%$  display window blinks.  
Set a numeral with **[▶]** and **[▲]** keys.  
The digit selected with **[▶]** key blinks.

Adjustable range: 0.0~100.0%



#### Finish

- ⑤ Press **[SEL]** key.

**Note:** When the setting is out of adjustable range, blinking Err is displayed for the setting parameter in question for a while and returns to the setting ③ or ④.


## 5.6 ●Character display

Display	Name	Explanation
000000	Error 0	Over range measurement.
Err-1	Error 1	Over ranged temperature measurement in temperature compensation and temperature conversion function.
Err-2	Error 2	Calculation error.
ErrSO	Error SO	When SOURCE is open.
ErrSE	Error SE	When SENSE is open.
Err in	Error in	Error of regulated current.
SEr	Set	Memory setting.
rScc	Test CC	Broken line detection, start of self-check.
rSEnd	Test end	Broken line detection, finish of self-check.
Err	Setting error	When setting parameter is out of range. Blinks for about 1 second.

## 6. Panel mount use

### 6.1 ● Assembly for mounting


When the meter is intended for panel mount use, use an optional mounting bracket.



- ① Remove the feet (4 parts) from the bottom of the meter.
- ② Fix the panel mount bracket to both sides of the meter (M4 × 15 flat head screws).
- ③ Insert the meter from the front of the panel and fix it to the panel with meter mounting bracket.

**Note:** When the meter is installed to a chassis etc. utilizing the tap holes of the meter, use the screw of the length 6 + thickness of meter (mm).

### 6.2 ● External dimensions when fitting panel mount brackets



## 7. Calibration

### 7.1 Materials to prepare

To calibrate the 3565, prepare the following standard resistors for calibration.


For resistance measurement ranges: 300m $\Omega$ , 3  $\Omega$ , 30  $\Omega$ , 300  $\Omega$ , 3k $\Omega$ , 30k $\Omega$ , 300k $\Omega$

For temperature measurement ranges: 100  $\Omega$  (0 $^{\circ}$ C), 172.17  $\Omega$  (190 $^{\circ}$ C)

**Note:** Select the calibration resistors whose accuracy secures the same of 3565.

### 7.2 Calibration method


#### 7.2.1 Calibration of resistance measuring range



- ① Turn off the power supply switch, then pressing **[OHM]** and **[TEMP]** keys simultaneously, switch ON the power supply. **CAL** is displayed on HI SET display window and the meter enters calibration mode.
- ② Press **[OHM]** key. OHM Lamp is lit up.
- ③ Connect the standard resistor with lead wires as the figure below shows. Select the standard resistor to suit each measuring range.
- ④ ZERO is calibrated by pressing **[▶]** key, and MAX by **[▲]** key. Make correct calibration for each range, Selecting it with **[RANGE]** key. When the calibration is correctly done, **CAL** blinks for a while on the display. In case that **Err** is displayed, it is out of the range to calibrate. Replace the resistor with that of correct value.
- ⑤ Standard resistance values for each range and display values are as follows.

Range	Standard resistance value	ZERO display value	MAX display value
300m $\Omega$	300m $\Omega$	0.00m $\Omega$	300.00m $\Omega$
3 $\Omega$	3 $\Omega$	0.0000 $\Omega$	3.0000 $\Omega$
30 $\Omega$	30 $\Omega$	0.000 $\Omega$	30.000 $\Omega$
300 $\Omega$	300 $\Omega$	0.00 $\Omega$	300.00 $\Omega$
3k $\Omega$	3k $\Omega$	0.0000k $\Omega$	3.0000k $\Omega$
30k $\Omega$	30k $\Omega$	0.000k $\Omega$	30.000k $\Omega$
300k $\Omega$	300k $\Omega$	0.00k $\Omega$	300.00k $\Omega$

- ⑥ When completed the calibration, turn OFF the power supply of the meter to release it from calibration mode. When the meter is powered ON again, it returns to measuring mode.






## 7.2.2 Calibration of temperature measuring range

- ① In the same manner as resistance measurement, press **TEMP** key, then the meter becomes calibration mode for temperature measurement ranges.
- ② Connect the standard resistor  $100\ \Omega$  as the figure below shows and press **▶** key, then ZERO is calibrated.
- ③ In the same way, connect the resistor  $172.17\ \Omega$  and press **▲** key to calibrate MAX.
- ④ Display values at calibration is as follows.

ZERO display value	MAX display value
$0.0^{\circ}\text{C}$	$190.0^{\circ}\text{C}$

- ⑥ When completed the calibration, turn OFF the power supply of the meter to release it from calibration mode. When the meter is powered ON again, it returns to measuring mode.



## 8. Specifications

### 8.1 ●Model name

Model name	Description
3565 -□	No data output
3565-01-□	With GP-IB
3565-03-□	With BCD data output (TTL level)
3565-04-□	With BCD data output (open collector)
3565-05-□	With RS-232C
3565-06-□	With RS-485

□ : Judgement output  
 Nil : Open collector NPN  
 RY : Relay output

### 8.2 ●Measuring range & accuracy

#### ■Resistance measurement (at SLOW sampling)

Measuring range	300mΩ	3 Ω	30 Ω	300 Ω	3kΩ	30kΩ	300kΩ
Resolution	10 μ Ω	100 μ Ω	1mΩ	10mΩ	100mΩ	1 Ω	10 Ω
Measuring current	100mADC		10mADC	1mADC		10 μ ADC	
Max. measurement voltage applied	30mV	300mV			3V	300mV	3V
Accuracy ※	Note 1	±(0.08% of rdg. +3 digits)					Note 2
Temperature coefficient	±(0.01% of rdg. +0.5 digits) / °C						
Open terminal voltage	7VDC Max.						

**Note 1:** ±(0.1% of rdg. + 8 digits)

**Note 2:** ±(0.1% of rdg. + 3 digits)

※Accuracy: Defined at 23°C±5°C, 45~75%RH.

When the sampling rate is MEDIUM, 3 digits are added to the accuracy at SLOW.

#### ■Resistance measurement (at FAST sampling)

Measuring range	300mΩ	3Ω	30Ω	300Ω	3kΩ
Resolution	100μΩ	1mΩ	10mΩ	100mΩ	1Ω
Measuring current	100mADC		10mADC	1mADC	
Max. measurement voltage applied	30mV	300mV			3V
Accuracy ※	±(0.2% of rdg. + 5 digits)				
Temperature coefficient	±(0.01% of rdg. + 0.1 digit) / °C				
Open terminal voltage	7VDC Max.				

※Accuracy: Defined at 23°C±5°C, 45~75%RH.

## ■ Temperature measurement

Measuring range	-19.9~199.9°C
Resolution	0.1°C
Accuracy ※	±(0.2% of rdg. +0.2°C)
Temperature coefficient	±(0.02% of rdg. +0.02°C) / °C
Sensor	Pt100Ω 3-wire system (lead wire resistance 5Ω or less)
Measuring current	Approx. 1mA

※Accuracy: Defined at 23°C±5°C, 45~75%RH.


## 8.3 ● General specifications

Measuring system	: 4 terminals system (resistance measurement).
Tolerable max. apply voltage	: 100V, AC, DC for all ranges. (10VDC at temperature measuring rang)
Measuring cable resistance	: 5Ω or less.
Display	: Green LED (character height 14.2mm). Resistance measurement : 35000 (3500 for FAST) Temperature measurement : 199.9 Provided with zero suppress function.
Over-range display	: Blinking with <b>■■■■</b> .
Unit display	: mΩ, Ω, kΩ, %, °C
Sampling rate	: SLOW : (4 times/sec.) MEDIUM : (20 times/sec.) FAST : (100 times/sec.)
Response speed	: SLOW : approx. 500ms MEDIUM : approx. 100ms FAST : approx. 50ms
Parameter retention	: Function, ranges, values etc. are memorized in EEPROM. Re-writable times 100,000 times Retention period 10 years
Insulation resistance	: Whole terminals – Enclosure 500VDC 100MΩ or more
Withstanding voltage	: Whole terminals– Enclosure 1500V AC for 1 minute Power source – Enclosure 1500V AC for 1 minute Measuring terminals – Output terminals 500V AC for 1 minute
Power supply voltage	: AC100~240V (50/60Hz)
Tolerance for supply voltage	: AC90~250V (50/60Hz)
Power consumption	: Approx. 13VA
Operating ambient temperature	: 0~50 °C
Storage temperature	: -20~70 °C
Weight	: Approx. 1kg.
Accessories	: Power supply cable with 3P→2P conversion plug ..... 1 pc. Remote connector ..... 1 pc. Instruction manual ..... 1 pc.

## 8.4 ● Table of initial set values (at delivery from factory)

Measuring range	300 $\Omega$
Memory 1~30	Resistance measurement, 300 $\Omega$ range
Comparator	HI SET: 300.00 $\Omega$ , LO SET: 000.00 $\Omega$
Ratio display function	Standard value: 300.00 $\Omega$ $\pm \Delta\%$ : 010.0%
Temperature compensation function	Standard temperature: 020.0°C Temperature coefficient: 3930ppm
Key lock	OFF
Buzzer	OFF setting, sound volume 5
Zero adjustment	OFF

## 8.5 ● External dimensions



## 8.6 ● Interface (option)

○ Following optional interfaces are prepared for use with Model 3565.

For handling of each interface, please refer to respective instruction manual of these interface.

GP-IB interface board	: 5811-01
BCD data output board (TTL)	: 5811-03
BCD data output board (open collector)	: 5811-04
RS-232C interface board	: 5811-05
RS-485 interface board	: 5811-06

○ Others

(1) Kelvin clip	: 5811-21B 5803-24
(2) Lead for calibration of resistance	: 5811-51
Lead for calibration of temperature	: 5811-52
Temperature sensor	: 5803-11
Panel mount bracket	: 5811-31

### Contact Information

Name : Tsuruga Electric Corporation  
Address : 1-3-23 Minami-Sumiyoshi, Sumiyoshi-ku, Osaka-shi  
558-0041 Japan

---

Instruction Manual  
Interface of BCD Data Output

**MODEL 5811-03,04**  
(for Model 3565)

---

I-01278

# Contents

<b>1. Specifications of BCD data input &amp; output</b> .....	2
1.1 MODEL 5811-03 (3565-03) .....	2
1.2 MODEL 5811-04 (3565-04) .....	2
<b>2. Arrangement of connector pins</b> .....	3
<b>3. Explanation of input/output signals</b> .....	4
3.1 Output signals .....	4
3.1.1 Measuring data output : 1, 2, 4, 8 ( $\times 10^0 \sim \times 10^4$ ) .....	4
3.1.2 Unit output : UNIT .....	4
3.1.3 Decimal point output : DP1~DP4 .....	4
3.1.4 Polarity output : POL .....	4
3.1.5 Over-range output : OVER .....	4
3.1.6 Strobe output : STROBE .....	4
3.2 Input signals .....	5
3.2.1 Data enable : OUTPUT ENABLE .....	5
3.2.2 Remote hold input : HOLD .....	5
3.2.3 Data selection input : SEL .....	5
3.2.4 Remote control input : INT./EXT. ....	6
3.2.5 Input of function : FUNCTION .....	6
3.2.6 Range input : RANGE .....	7
<b>4. Operation</b> .....	8
4.1 Resistance measurement .....	8
4.2 Temperature measurement .....	8
4.3 Temperature compensation .....	8
4.4 Ratio display .....	8
4.5 Temperature conversion .....	9
<b>5. Timing chart</b> .....	10
5.1 Data output .....	10
5.2 Timing chart for switching-over of function .....	10

With BCD data output board, this interface can perform the remote control of measuring function and measuring range as well as output measuring data of the model 3565.

## **! CAUTION**

**Switch OFF the power of the main unit and pull out the power cord plug.  
Do not short-circuit or apply voltage to output.**


## **1. Specifications of BCD data input & output**

### **1.1 MODEL 5811-03 (3565-03)**


BCD data is output by TTL level.

Output system : Parallel BCD code, positive logic.

“L” level is output by logic “0”, and “H” level by logic “1”.



Input level :  $I_{IL}$  -1mA  
“L” = 0.8V or less  
“H” = 3.5 ~ 5V




Output level : TTL level  
 $F_o = 2$

### **1.2 MODEL 5811-04 (3565-04)**


BCD data is output by open collector

Output system : Parallel BCD code.

“OFF” is output by logic “0”, and “ON” by logic “1”.




Input level :  $I_{IL}$  -1mA  
“L” = 0.8V or less  
“H” = 3.5 ~ 5V



Output capacity : DC30V, 30mA

## 2. Arrangement of connector pins



Signal name		Pin No.		Signal name	
UNIT	0	1	26	4	UNIT
	1	2	27	5	
	2	3	28	6	
	3	4	29	7	
$\times 10^0$	1	5	30	1	$\times 10^1$
	2	6	31	2	
	4	7	32	4	
	8	8	33	8	
$\times 10^2$	1	9	34	1	$\times 10^3$
	2	10	35	2	
	4	11	36	4	
	8	12	37	8	
$\times 10^4$	1	13	38	POL	
OUTPUT ENABLE		14	39	OVER	
HOLD		15	40	STROBE	
DP1		16	41	1	SEL
DP2		17	42	2	
DP3		18	43	4	
DP4		19	44	2	$\times 10^4$
FUNCTION	1	20	45	1	RANGE
	2	21	46	2	
	4	22	47	4	
	8	23	48	NC	
INT. / EXT.		24	49		
DATA COM		25	50	DATA COM	

Connector: (Anphenol) 57-30500

**Note:** Do not use NC pin as it is connected to the internal circuit.



### 3. Explanation of input/output signals

#### 3.1 Output signals

##### 3.1.1 Measuring data output : 1, 2, 4, 8 ( $\times 10^0 \sim \times 10^4$ )

Measured data is output with parallel BCD code.

**Note:** When  $\times 10^0$  digit is blank (or sampling rate is FAST), 0 is output.

##### 3.1.2 Unit output : UNIT

“Unit” data is output with 8 bit code.

Table of unit code:

Unit	UNIT							
	7	6	5	4	3	2	1	0
<b>m</b>	1	0	0	1	1	0	0	0
	1	1	1	1	1	1	1	0
<b>k</b>	0	1	1	0	0	1	0	1
<b>°C</b>	1	0	1	1	0	0	0	1
<b>%</b>	1	1	1	0	0	0	0	0

##### 3.1.3 Decimal point output : DP1~DP4

Position of decimal point is output with 4 bit code.

Table of output code:

Display	Output			
	DP4	DP3	DP2	DP1
<b>3 5 0 . 0 0 ( 3 5 0 . 0 )</b>	1	1	0	1
<b>3 5 . 0 0 0 ( 3 5 . 0 0 )</b>	1	0	1	1
<b>3 . 5 0 0 0 ( 3 . 5 0 0 )</b>	0	1	1	1

$\times 10^0$  digit is blank.

##### 3.1.4 Polarity output : POL

“1” is output for plus polarity.

“0” is output for minus polarity.

##### 3.1.5 Over-range output : OVER

Error 0 : When the data exceeded 35000 (3500 ) or the measured temperature exceeded the measuring range in temperature measurement, OVER becomes “1” and the data 00000 is output.

Error 1 : When the data exceeded the temperature measuring range in temperature compensation function and temperature conversion function, OVER becomes “1” and the data 00001 is output.

Error 2 : When the calculation is faulty, OVER becomes “1” and the data 00002 is output.


Error 3 : When the data selection input is out of the designated codes, OVER becomes “1” and the data 00003 is output.

##### 3.1.6 Strobe output : $\overline{\text{STROBE}}$

At renewal of data, “L” pulse is output as the figure below shows.

Catching this rising point, transact the data.

**Note:** ON is output when the specifications are provided with the open collector output.



Sampling rate	t m s
FAST	Approx. 1ms
SLOW, MEDIUM	Approx. 10ms

## 3.2 Input signals

### 3.2.1 Data enable : OUTPUT ENABLE

All the output except  $\overline{\text{STROBE}}$  become “high impedance” status at “L” level.

### 3.2.2 Remote hold input : $\overline{\text{HOLD}}$

At “H” level, sampling is done and the measuring data is sequentially output.

At “L” level, sampling is stopped and, the BCD data and display value are held.

During the hold, switch operation on the front panel is not accepted.

### 3.2.3 Data selection input : SEL

By making an input of selection code, in measurement of temperature compensation, temperature conversion or ratio display, the measuring data can also be output in addition to the displayed data.

When making the data selection, do it after getting the display value and data in hold status.

**Note 1:** If it is done without holding, the display value and output data may be different.

**Note 2:** Display remains unchanged even if the status becomes data selection status.

Example: The display value, during the temperature compensation function in operation, is the conversion value ( $R_T$ ).

If the data output of ambient temperature (t) or resistance value ( $R_t$ ) at the ambient temperature t is necessary, select the output data by making an input of selection code.

How-to-select:

Make an input of selection code in the table and select the necessary data.

**Table of data output & selection code**


Selection code		4	2	1	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1	4	2	1
		L	L	L	L	L	H	L	H	L	L	H	H	H	L	L	H	L	H	H	H	L	H	H	L
Function		OHM			OHM			OHM			OHM			OHM			OHM			OHM			OHM		
At resistance measurement		OHM			OHM			OHM			OHM			OHM			OHM			OHM			OHM		
At temperature measurement		TEMP			TEMP			TEMP			TEMP			TEMP			TEMP			TEMP			TEMP		
At temperature compensation		Err3			Rt			t			Err3			Err3			Err3			Err3			R <sub>T</sub>		
At ratio display		Err3			R <sub>s</sub>			R <sub>x</sub>			Err3			Err3			Err3			Err3			X		
At temperature conversion	T <sub>1</sub> measurement	Err3			T <sub>1</sub>			R <sub>1</sub>			Err3			Err3			Err3			Err3			R <sub>1</sub>		
	T <sub>2</sub> measurement	Err3			Err3			Err3			T <sub>2</sub>			R <sub>2</sub>			Err3			Ter			R <sub>2</sub>		
	TE conversion	Err3			T <sub>1</sub>			R <sub>1</sub>			T <sub>2</sub>			R <sub>2</sub>			Err3			Ter			TE		

**Note 1:**

Function	Display	Contents
At resistance measurement	OHM	Resistance value
At temperature measurement	TEMP	Temperature
At temperature compensation	$R_t$ T $R_T$	Resistance value at ambient temperature ( ) Ambient temperature Compensation resistance
At ratio display	$R_S$ $R_X$ X	Standard resistance value Measuring resistance value Ratio
At temperature conversion	$T_1$ $R_1$ $T_2$ $R_2$ Ter Te	Ambient temperature at the start of the test Coil resistance at temperature $T_1$ Ambient temperature at the end of the test Coil resistance at temperature $T_2$ Increased temperature of coil by TE calculation is sequentially output. Temperature increase of coil at switching to Te

**Note 2:** When the data selection input is out of the designated codes, “Error 3” signal is output.  
(Err3: OVER signal becomes “1” and the data 00003 is output.)

Timing chart for data selection



### 3.2.4 Remote control input : INT. / $\overline{\text{EXT}}$ .

By making “L” level, the following operations can be remote-controlled.

In this case, the switch operation from the front panel is disabled.

Selection of function

Selection of range

**Note:** During the hold, no control is possible.

During the remote-controlled memory mode, no function or no range can be selected.

### 3.2.5 Input of function : FUNCTION

By designating a function code, each function can be remote-controlled. When inputting the function code, do it after setting INT. /  $\overline{\text{EXT}}$ . input to “L” level.

Function		8	4	2	1
Resistance measurement		H	L	L	H
Temperature measurement		H	L	L	L
Temperature compensation		L	H	L	L
Ratio display	OHM RATIO	L	H	H	H
	T. C RATIO	L	H	L	H
Temperature conversion	Te CLR	L	L	H	H
	T <sub>1</sub>	L	L	H	L
	T <sub>2</sub>	L	L	L	H
	Te	L	L	L	L


**Note:** Setting other than the above is ineffective.

### 3.2.6 Range input : RANGE

By making an input of range code, it is possible to remotely select a resistance.  
When inputting the range code, do it after setting INT. / EXT. input to “L” level.

RANGE			Range
4	2	1	
L	L	L	Resistance measurement Auto range
L	L	H	Resistance measurement 300m
L	H	L	Resistance measurement 3
L	H	H	Resistance measurement 30
H	L	L	Resistance measurement 300
H	L	H	Resistance measurement 3k
H	H	L	Resistance measurement 30k
H	H	H	Resistance measurement 300k

Timing chart for switching-over of range



## 4. Operation

---

### 4.1 Resistance measurement

---

Refer to the article 5.1 of this manual.

Make the remote control input (INT. /  $\overline{\text{EXT.}}$ ) “L” level.

Input a resistance measurement code to the function (FUNCTION).

Input a range code to the range (RANGE) and select a resistance range.

Start measurement.

### 4.2 Temperature measurement

---

Refer to the article 5.2 of this manual.

Make the remote control input (INT. /  $\overline{\text{EXT.}}$ ) “L” level.

Input a temperature measurement code to the function (FUNCTION).

Start measurement.

### 4.3 Temperature compensation

---

Refer to the article 5.3 of this manual.

Make the remote control input (INT. /  $\overline{\text{EXT.}}$ ) “L” level.

**Note 1:** Setting of standard temperature and temperature coefficient:

Make the remote control input (INT. /  $\overline{\text{EXT.}}$ ) “H” level, and set with the switch on the front panel.

Select a resistance range with the range (RANGE).

Input a temperature compensation code to the function (FUNCTION).

Start measurement.

### 4.4 Ratio display

---

Refer to the article 5.5 of this manual.

Make the remote control input (INT. /  $\overline{\text{EXT.}}$ ) “L” level.

**Note :** When making numeral setting of standard resistance value:

Make the remote control input (INT. /  $\overline{\text{EXT.}}$ ) “H” level, and set with the switch on the front panel.

Select a resistance range with the range (RANGE).

Input OHM RATIO or T.C RATIO code to the function (FUNCTION).

OHM RATIO : Display of ratio at resistance measurement

T.C RATIO : Display of ratio at temperature compensation

Start measurement.

## 4.5 Temperature conversion

Refer to the article 5.4 of this manual.

Make the remote control input (INT. /  $\overline{\text{EXT.}}$ ) "L" level.

Input the Te CLR code. (It clears internal memory.)

Connect a test sample to measuring input. The lamps of OHM and TE of the main unit turn ON.

Input the T<sub>1</sub> code.

Input the T<sub>2</sub> code.

T<sub>1</sub> and R<sub>1</sub> at input are memorized.

The OHM lamp turns off.

Disconnect the measuring input and make a conductance test.

After finishing the conductance test, connect the test sample to the measuring input.

Input the T.E code.


Temperature increase at input is memorized as Te.

Read-out of each data: After the finish of temperature conversion, the data T<sub>1</sub>, T<sub>2</sub>, R<sub>1</sub>, R<sub>2</sub> and TE of each channel is output.

**Note 1:** Perform the measurement separately from the conductance test. If the test sample is in the condition being conducted, the measurement can not be made.


**Note 2:** Zero-adjustment function can not be used.

### Performance



## 5. Timing chart

### 5.1 Data output




$T_s$  : Sampling rate  
(SLOW : 250ms MEDIUM : 50ms FAST : 10ms)

$T_{sh}$  :  $T_s + 3ms$

//// section High impedance

### 5.2 Timing chart for switching-over of function



---

Instruction Manual  
Interface of GP-IB

**MODEL 5811-01**  
**(for Model 3565)**

---

**I-01324**





## Contents

1. FUNCTION .....	2
1.1 Interface .....	2
1.2 BUS Driver System .....	2
1.3 Delimiter .....	2
1.4 Address Setting .....	2
1.5 Remote Switch .....	3
2. EXPLANATION OF COMMAND .....	3
2.1 Program Data .....	3
2.2 Detail of Program Data .....	3
2.2.1 BUZZ= (Setting of Buzzer) .....	3
2.2.2 BUZZ? (Readout of Buzzer) .....	4
2.2.3 MODE= (Change of Mode) .....	4
2.2.4 MEM=CALL (Call of Memory) .....	4
2.2.5 MEM <span style="border: 1px solid black; padding: 0 2px;">No</span> ? (Readout of Memory Set Data) .....	5
2.2.6 MEM= (Setting of Memory Data) .....	6
2.2.7 COMP= (Setting of Comparator) .....	7
2.2.8 COM? (Readout of Comparator Data) .....	7
2.2.9 DATA1? (Readout of Measured Data) .....	8
2.2.10 DATA? (Designation of Data Output, 3572 Compatible) .....	11
2.2.11 FUNCTION= (Measuring Function) .....	12
2.2.12 FUNC? (Readout of Function) .....	12
2.2.13 HOLD= (Setting of Hold) .....	13
2.2.14 HOLD? (Readout of Hold Status) .....	13
2.2.15 RANGE= (Setting of Measuring Range) .....	14
2.2.16 RANGE? (Readout of Measuring Range) .....	14
2.2.17 RATIOSTD= (Setting of Ratio Referential Value) .....	15
2.2.18 RATIOSTD? (Readout of Ratio Referential Value) .....	15
2.2.19 RST= (Reset of Judgement) .....	16
2.2.20 RST? (Readout of Judgement Reset Status) .....	16
2.2.21 SAMPLING= (Setting of Sampling Rate) .....	17
2.2.22 SAMPLING? (Readout of Sampling Rate) .....	17
2.2.23 SRQ= (Setting of Service Request) .....	18
2.2.24 SRQ? (Readout of Service Request Status) .....	18
2.2.25 TC= (Setting of T.C Standard Temperature, Temperature Coefficient) .....	19
2.2.26 TC? (Readout of T.C Standard Temperature, Temperature Coefficient) .....	19
2.2.27 ZEROADJ= (Setting of Zero Adjustment) .....	20
2.2.28 ZEROADJ? (Readout of Zero Adjustment Status) .....	20
3. SERVICE REQUEST .....	21
3.1 Status Bite .....	21
4. DEVICE CLEAR FUNCTION .....	21
5. DEVICE TRIGGER FUNCTION .....	21

## 1. FUNCTION

### 1.1 Interface

Table 1-1

Function	Description
SH1	All the receiver handshake functions are provided.
AH1	All the transmitter handshake functions are provided.
T8	Basic talker function.
	Talker release function with MLA.
L4	Basic listener function.
	Listener release function with MTA.
SR1	Service request function is provided.
RL0	No remote local function is provided.
PP0	No parallel pole function is provided.
DC1	Device clear function is provided.
DT1	Device trigger function is provided.
C0	No control function is provided.

### 1.2 BUS Driver System

Open collector driver (In accordance with IEEE488-1978)

### 1.3 Delimiter

When  $\overline{C_R} + \overline{L_F}$  or EOI “True” is received, it is recognized as delimiter.


### 1.4 Address Setting

Table 1-2

Address	Dip switch				
	5	4	3	2	1
0	-	-	-	-	-
1	-	-	-	-	O
2	-	-	-	O	-
3	-	-	-	O	O
4	-	-	O	-	-
5	-	-	O	-	O
6	-	-	O	O	-
7	-	-	O	O	O
8	-	O	-	-	-
9	-	O	-	-	O
10	-	O	-	O	-
11	-	O	-	O	O
12	-	O	O	-	-
13	-	O	O	-	O
14	-	O	O	O	-
15	-	O	O	O	O

Address	Dip switch				
	5	4	3	2	1
16	O	-	-	-	-
17	O	-	-	-	O
18	O	-	-	O	-
19	O	-	-	O	O
20	O	-	O	-	-
21	O	-	O	-	O
22	O	-	O	O	-
23	O	-	O	O	O
24	O	O	-	-	-
25	O	O	-	-	O
26	O	O	-	O	-
27	O	O	-	O	O
28	O	O	O	-	-
29	O	O	O	-	O
30	O	O	O	O	-

Dip switched on the rear



Up to max. 15 units can be connected on the GP-IB, so it is necessary to set the address for each device. The address 31 can not be set. Even if it is set, it is internally transacted as 31.

**Note:** Make the address setting with the power off.



### 2.2.2 BUZZ? (Readout of Buzzer)

**Function** To read out the mode and volume of buzzer.

**Structure** BUZZ?

**Transmission**

BUZZ?  $\begin{smallmatrix} \text{C} \\ \text{R} \end{smallmatrix} \begin{smallmatrix} \text{L} \\ \text{F} \end{smallmatrix}$

**Reply**

BUZZ=GOOD, 03  $\begin{smallmatrix} \text{C} \\ \text{R} \end{smallmatrix} \begin{smallmatrix} \text{L} \\ \text{F} \end{smallmatrix}$   
                   ①   ②

①Data of mode

②Data of volume 01~10

### 2.2.3 MODE= (Change of Mode)

**Function** To switch over memory mode or manual mode.

**Structure** MODE= **MODE**

MODE= : Command to change the mode.

**MODE** : “MEMORY” designates memory mode.  
           “MANUAL” designates manual mode.

**Transmission**

Designate the memory mode.

MODE=MEMORY  $\begin{smallmatrix} \text{C} \\ \text{R} \end{smallmatrix} \begin{smallmatrix} \text{L} \\ \text{F} \end{smallmatrix}$

### 2.2.4 MEM=CALL (Call of Memory)

**Function** To call a memory designated by No.

**Note:** Make a setting after switching over to the memory mode.

**Structure** MEM=CALL **NO.**

MEM= : Command to set a memory number.

**NO.** : Designates the memory “01” ~ “30”.

**Transmission**

Set to memory No.01, afterwards it actions as memory No.01.

MEM=CALL01  $\begin{smallmatrix} \text{C} \\ \text{R} \end{smallmatrix} \begin{smallmatrix} \text{L} \\ \text{F} \end{smallmatrix}$

### 2.2.5 MEM ? (Readout of Memory Set Data)

**Function** To read out the memory data designated by No.

**Note:** Make a setting after switching over to the memory mode.

**Structure** MEM  ?

: Designates the memory “01” ~ “30”.

**Transmission**

MEM01? <sub>R</sub> <sub>F</sub>

**Reply**

MEM=NO.01, OHM  , 300mOHM, H35.000\_OHM, L100.00\_OHM <sub>R</sub> <sub>F</sub>  
                   ①       ②       ③                   ④                   ⑤

- ① Shows the memory number (Data length = 5)
- ② Shows the function (Data length = 10)
- ③ Shows the range (Data length = 7)
- ④ Shows HI data of the memory (Data length = 11)
- ⑤ Shows LO data of the memory (Data length = 11)

### 2.2.6 MEM= (Setting of Memory Data)

**Function** To set a memory data.

**Note:** Make a setting after switching over to the memory mode.

**Structure** MEM= **NO.** , **FUNC** , **RANGE** , H **HI SET** , L **LO SET**

MEM= : Command to set the memory number.

**NO.** : Designates the memory number “01” ~ “30”.

**FUNC** : Function “OHM”, “OHM-RATIO”, “TC-RATIO”, “TC”

**RANGE** : Range, designates either one - “300mOHM”, “3OHM”, “30OHM”, “300OHM”, “3kOHM”, “30kOHM”, “300kOHM”

**HI SET** : Sets data for comparator’s high limit value.  
(Range of adjustable numeral 0~35000)

**LO SET** : Sets data for comparator’s low limit value.  
(Range of adjustable numeral 0~35000)

**Note 1:** HI SET and LO SET are to be set adding a unit and a decimal point.  
Setting example: 35.000kOHM

**Note 2:** When the FUNC is RATIO, set the standard value for HI SET and deviation  $\Delta$  for LO SET.  
Setting example: H100.00OHM, L10.0%

**Note 3:** Setting of a values for temperature compensation is made at “TC=”  
(article 2.2.25).

#### Transmission

- When the function is set to temperature compensation.

Set FUNC of memory No.1 to OHM, RANGE to 3k $\Omega$ , HI SET to 2.0000k $\Omega$ , LO SET to 1.5000k $\Omega$  respectively.

MEM=01, OHM, 3kOHM, H2.0000kOHM, L1.5000kOHM  $\text{C}_R \text{F}_F$

- When the function is set to ratio display function.

Set FUNC of memory No.10 to OHM-RATIO, RANGE to 300m $\Omega$ , REF to 200m $\Omega$ ,  $\Delta$  to 10.0% respectively.

MEM=10, OHM-RATIO, 300mOHM, H200.00mOHM, L010.0%  $\text{C}_R \text{F}_F$

### 2.2.7 COMP= (Setting of Comparator)

**Function** To set high and low limit values and their unit of comparator.  
**Note:** When the measuring function is RATIO (ratio display) or TE (temperature conversion), setting is not allowed.

**Structure** COMP= H **HI SET** , L **LO SET**

COMP= : Command to set a comparator.

**HI SET** : Sets a data for comparator's high limit value.  
 (Range of adjustable numeral 0~35000)

**LO SET** : Sets a data for comparator's low limit value.  
 (Range of adjustable numeral 0~35000)

**Note 1:** HI SET and LO SET are to be set adding a unit and decimal point.  
 Setting example: 35.000kOHM

**Note 2:** Set the same unit and decimal point for HI SET and LO SET.

**Transmission**

Set HI SET to 2.0000kΩ and LO SET to 1.5000kΩ respectively.

COMP=H2.0000kOHM, L1.5000kOHM  $\begin{bmatrix} C_R \end{bmatrix} \begin{bmatrix} L_F \end{bmatrix}$

### 2.2.8 COMP? (Readout of Comparator Data)

**Function** To read out high and low limit values and their unit of comparator.  
**Note:** When the measuring function is RATIO (ratio display) or TE (temperature conversion), read-out is not possible.

**Structure** COMP?

**Transmission**

COMP?  $\begin{bmatrix} C_R \end{bmatrix} \begin{bmatrix} L_F \end{bmatrix}$

**Reply**

COMP=H300.00kOHM, L100.00kOHM  $\begin{bmatrix} C_R \end{bmatrix} \begin{bmatrix} L_F \end{bmatrix}$

①                      ②                      ③

①Shows comparator data output (Data length = 4)

②Shows comparator HI data (Data length = 11)

③Shows comparator LO data (Data length = 11)



## 2.2.9 DATA1? (Readout of Measured Data)

**Function** To read out measured data.

**Structure** DATA1?

DATA1? : Command to output the measured data.

**Transmission**

DATA1?  $\text{C}_R$   $\text{L}_F$

**Reply**

**Note 1:** \_ is space (2O<sub>H</sub>),  $\text{C}_R$  is carriage return (0D<sub>H</sub>),  $\text{L}_F$  is line feed (0A<sub>H</sub>).

**Note 2:** Data are all JIS punctuation point code.

### ● Resistance measurement

OHM\_ \_ \_ :350.00\_kOHM,  $\text{L}_F$

① ②

① Shows the resistance measurement output (Data length = 6)

② Measured data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER” is output.

### ● Temperature measurement

TEMP\_ \_ : \_ \_100.0\_’C\_ ,  $\text{L}_F$

①

① Shows the temperature measurement output (Data length = 6)

② Measured data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER” is output.

### ● Ratio measurement

RATIO\_ :123.45\_%\_ \_ \_ , \_R\_ \_ \_ \_ \_ : 123.45\_mOHM, \_set\_ \_ \_ :100.00\_mOHM,  $\text{L}_F$

① ② ③ ④ ⑤ ⑥

① Shows the measurement data output (Data length = 6)

② Ratio measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_mOHM” is output.

In case of measurement error (Err2 display), “\_ERR2\_ \_mOHM” is output.

③ Shows the resistance measurement value (Data length = 7)


④ Resistance measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_OHM” is output.

⑤ Shows the standard value output (Data length = 7)

⑥ Standard the value data (Data length = 11)

● Temperature compensation measurement

TC\_\_\_\_\_ : 127.76\_ \_OHM, \_R\_\_\_\_\_ : 130.02\_ \_OHM, \_T\_\_\_\_\_ : \_ \_24.5\_ ' C\_ \_ , 

①                      ②                                      ③                                      ④                                      ⑤                                      ⑥

① Shows the output of temperature compensation measurement value (Data length = 6)

② Data of temperature compensation measurement (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

In case of measurement error (Err1 display), “\_ERR1\_ \_OHM” is output.

③ Shows the output of resistance measurement value (Data length = 7)

④ Resistance measurement data (Data length = 11)


In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

⑤ Shows the output of temperature measurement value (Data length = 7)

⑥ Temperature measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

● Temperature conversion measurement (T1)

R1\_\_\_\_\_ : 130.62\_ \_OHM, \_T1\_\_\_\_\_ : \_ \_24.5\_ ' C\_ \_ , 

①                      ②                                      ③                                      ④

① Shows the output of temperature conversion (T1) measurement value (Data length = 6)

② Data of temperature conversion (T1) measurement (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.


In case of measurement error (Err1 display), “\_ERR1\_ \_OHM” is output.

③ Shows the output of temperature measurement value (Data length = 7)

④ Temperature measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

● Temperature conversion measurement (T2)

R2\_\_\_\_\_ : 1.2345\_ kOHM, \_T2\_\_\_\_\_ : \_ \_24.5\_ ' C\_ \_ , 

①                      ②                                      ③                                      ④

① Shows the output of temperature conversion (T2) measurement value (Data length = 6)

② Data of temperature conversion (T2) measurement (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

In case of measurement error (Err1 display), “\_ERR1\_ \_OHM” is output.

③ Shows output of temperature measurement value (Data length = 7)

④ Temperature measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

● Temperature conversion calculation (T, E)

Te\_ \_ \_ \_ : \_ \_ 14.3\_ ' C \_ \_ , \_R2\_ \_ \_ \_ : 1.2345\_ \_OHM, \_T2\_ \_ \_ \_ : \_ \_ 24.5\_ ' C \_ \_ , \_  
 ① ② ③ ④ ⑤ ⑥  
 R1\_ \_ \_ \_ : 130.66\_ \_ OHM, \_T1\_ \_ \_ \_ : \_ \_ 24.5\_ ' C \_ \_ ,  $\square_F$   
 ⑦ ⑧ ⑨ ⑩

① Shows the output of temperature conversion calculation (Data length = 6)

② Measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

In case of measurement error (Err1 display), “\_ERR1\_ \_OHM” is output.

In case of measurement error (Err2 display), “\_ERR2\_ \_OHM” is output.

③ Shows the output of temperature conversion (T2) measurement value (Data length = 7)

④ Shows the temperature conversion (T2) measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

⑤ Shows the temperature measurement value output (Data length = 7)

⑥ Temperature measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

⑦ Shows the output of temperature conversion (T1) measurement value (Data length = 7)

⑧ Shows the temperature conversion (T1) measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

⑨ Shows the temperature measurement value output (Data length = 7)

⑩ Temperature measurement data (Data length = 11)

In case of over-range measurement (blinking with 00000), “\_ \_OVER\_ \_OHM” is output.

**Note: ③, ④, ⑤ and ⑥ output the measurement data of T2.**

**⑦, ⑧, ⑨ and ⑩ output the measurement data of T1.**

### 2.2.10 DATA? (Designation of Data Output, 3573 Compatible)

**Function** To designate the measured data as the data to be read in GP-IB.

**Structure** DATA?

DATA? : Command to output the measured data.

**Transmission**

DATA?  $\boxed{C_R} \boxed{L_F}$

**Reply**

① Resistance measurement

OHM=199.99kOHM, JUDGE=HIGH LOW  $\boxed{C_R} \boxed{L_F}$

② Temperature measurement

TEMP=0100.0 'C  $\boxed{C_R} \boxed{L_F}$

③ Ratio measurement

RATIO=0123.4%, Rs=1.0000\_OHM, Rx=1.2345\_OHM, JUDGE=GOOD  $\boxed{C_R} \boxed{L_F}$

④ Temperature compensation measurement

T.C=127.76mOHM, R=130.02mOHM, TEMP=0024.5 'C, JUDGE=GOOD  $\boxed{C_R} \boxed{L_F}$

⑤ Temperature conversion T1 measurement

R1=130.66kOHM, T1=0024.5 'C, JUDGE=NULL  $\boxed{C_R} \boxed{L_F}$

⑥ Temperature conversion T2 measurement

R2=130.66kOHM, T2=0024.5 'C, JUDGE=NULL  $\boxed{C_R} \boxed{L_F}$

⑦ Temperature conversion T.E calculation

T.E=0014.3 'C, R1=130.66kOHM, T1=0024.5 'C, R2=123.45kOHM, T2=0024.5 'C,  
JUDGE=NULL  $\boxed{C_R} \boxed{L_F}$

**Note:** JUDGE output

At GO	:	JUDGE=GOOD
At HI	:	JUDGE=HIGH
At LO	:	JUDGE=LOW
No judgement output	:	JUDGE=NULL
At Err1, Err2	:	JUDGE=HIGH LOW

### 2.2.11 FUNCTION= (Measuring Function)

**Function** To designate a measuring function.

**Structure** FUNCTION = **Function Code**

FUNCTION = : Command to set the measuring function.

**Function Code** : As the Table 2-1 shows.

Measuring function can also be designated with the following structure.

**Structure** M **Data**

M = : Command to set the measuring function.

**Data** : Designates a function with “0” ~ “9”.

**Table 1-2**

Function Code	Data	Measuring Function
OHM	M0	Resistance measurement
TEMP	M1	Temperature measurement
OHM-RATIO	M2	Ratio measurement
TC-RATIO	M3	Ratio standard value measurement
TC	M5	Temperature compensation measurement
TE-CLEAR	M6	Data clear of temperature conversion measurement
TE	M7	Temperature conversion (T.E) calculation
T1	M8	Temperature conversion (T1) measurement
T2	M9	Temperature conversion (T2) measurement

**Transmission**

Set the resistance measurement to measuring function.

FUNCTION=OHM  $\text{C}_R$   $\text{L}_F$

M0  $\text{C}_R$   $\text{L}_F$

### 2.2.12 FUNC? (Readout of Function)

**Function** To read out the type of measuring function.

**Structure** FUNC?

FUNC? : Command to output the measuring function.

**Transmission**

FUNC?  $\text{C}_R$   $\text{L}_F$

**Reply**

FUNCTION=OHM  $\text{C}_R$   $\text{L}_F$

①

②

①Shows output of function data (Data length = 8).

②Shows measuring function data.

**2.2.13 HOLD= (Setting of Hold)**

**Function** To set start and release of the hold.

**Structure** HOLD = **ON/OFF**

HOLD = : Command to set the hold.

**ON/OFF** : Stops sampling and holds with “ON”.  
Designates the release of hold with “OFF”.

Measuring function can also be designated with the following structure.

**Structure** **H0/H1**

H1 : Stops sampling and holds.

H0 : Designates the release of hold.

**Transmission**

Set hold to ON.

HOLD=ON  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

**2.2.14 HOLD? (Readout of Hold Status)**

**Function** To read out the setting status of hold.

**Structure** HOLD?

**Transmission**

HOLD?  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

**Reply**

HOLD=ON  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

① ②

①Shows the data output of hold (Data length = 4)

②Shows the setting status of hold.

### 2.2.15 RANGE= (Setting of Measuring Range)

**Function** To set the range of resistance measurement.

**Structure** RANGE = **Range**

RANGE = : Command to set the measuring range.

**Range** : Sets the range 300mΩ ~ 300kΩ in resistance measurement.

When the auto range is required, set AUTO.

Range of resistance and voltage measurement can also be designated with the following structure.

**Structure** R **Data**

R : Command to set the measuring range.

**Data** : Designates a range with "0" ~ "9".

**Table 2-2**

Range Code	Data	Measuring Range
300mOHM	R0	300mΩ
3OHM	R1	3Ω
30OHM	R2	30Ω
300OHM	R3	300Ω
3kOHM	R4	3kΩ
30kOHM	R5	30kΩ
300kOHM	R6	300kΩ
AUTO	R9	Auto range

**Transmission**

Set the measuring range to 30Ω.

RANGE=30OHM **C<sub>R</sub>** **L<sub>F</sub>**

### 2.2.16 RANGE? (Readout of Measuring Range)

**Function** To read out the set measuring range.

**Structure** RANGE?

**Transmission**

RANGE? **C<sub>R</sub>** **L<sub>F</sub>**

**Reply**

RANGE=30kOHM **C<sub>R</sub>** **L<sub>F</sub>**

① ②

① Shows data output of range (Data length = 5)

② Shows setting status of range.

### 2.2.17 RATIOSTD= (Setting of Ratio Referential Value)

**Function** To set the referential and deviation value of the ratio display.  
**Note:** When the measuring function is other than ratio display function, the setting is not possible.

**Structure** RATIOSTD = **Ref** ,  **$\pm \Delta$**

RATIOSTD = : Command to set the ratio referential value.

**REF** : Referential resistance value.

**$\pm \Delta$**  : Deviation  $\Delta\%$  data (00.0~100.0%)

**Transmission**

Set the referential resistance to  $30\ \Omega$  and deviation  $\Delta\%$  to 20.0%

RATIOSTD=10.00kOHM, 20.0% **C<sub>R</sub>** **L<sub>F</sub>**

### 2.2.18 RATIOSTD? (Readout of Ratio Referential Value)

**Function** To read out the data of ratio referential value.

**Structure** RATIOSTD?

**Transmission**

RATIOSTD? **C<sub>R</sub>** **L<sub>F</sub>**

**Reply**

RATIOSTD =100.00kOHM, 020.0% **C<sub>R</sub>** **L<sub>F</sub>**

①

②

③

①Shows the output of ratio standard data(Data length = 8)

②Shows the referential value data (Data length = 10)

③Shows the deviation  $\Delta\%$  data (Data length = 6)



**2.2.19 RST= (Reset of Judgement)**

**Function** To make ON/OFF of reset for the comparator judgement.  
(Resets the comparator output and makes the comparator display OFF.)

**Structure** RST = ON/OFF

RST = : Command to set the reset of judgement.

ON/OFF : Designates the reset of judgement output with “ON”.  
Designates the release of reset with “OFF”.

Reset can also be designated with the following structure.

**Structure** C0/C1

C0 : Releases reset.

C1 : Resets judgement.

**Transmission**

Resets the output of comparator judgement.

RST=ON  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

● One shot sampling hold

During the hold status of 3565, one shot sampling hold can be made with reset OFF following the reset ON.

**2.2.20 RST? (Readout of Judgement Reset Status)**

**Function** To read out the reset status of comparator judgement.

**Structure** RST?

**Transmission**

RST?  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

**Reply**

RST =OFF  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

①

②

①Shows the output of reset data. (Data length = 3)

②Shows the status of reset.

### 2.2.21 SAMPLING= (Setting of Sampling Rate)

**Function** To set a sampling rate.  
Sampling rate of temperature measurement is fixed at 4 times/sec. and not changeable.

**Structure** SAMPLING = SLOW/MEDIUM/FAST

SAMPLING = : Command to set a sampling rate.

SLOW/MEDIUM/FAST : Designates  
4 times/sec. with "SLOW".  
Designates 20 times/sec. with "MEDIUM".  
Designates 100 times/sec. with "FAST".

**Structure** S Data

S : Command to set a measurement sampling rate.  
Data : Designates the sampling rate with "0" ~ "2".

**Table 2-3**

	Code	Sampling rate
SLOW	S0	Low speed (4 times/sec.)
MEDIUM	S1	Medium speed (20 times/sec.)
FAST	S2	Fast speed (100 times/sec.)

**Transmission**

Set the sampling rate to low speed (4 times/sec).

SAMPLING=SLOW  $\begin{bmatrix} C_R \\ L_F \end{bmatrix}$

### 2.2.22 SAMPLING? (Readout of Sampling Rate)

**Function** To read out the status of sampling rate.

**Structure** SAMPLING?

**Transmission**

SAMPLING?  $\begin{bmatrix} C_R \\ L_F \end{bmatrix}$

**Reply**

SAMPLING =SLOW  $\begin{bmatrix} C_R \\ L_F \end{bmatrix}$

① ②

①Shows the output of sampling data. (Data length = 8)

②Shows the status.

### 2.2.23 SRQ= (Setting of Service Request)

**Function** To set a service request.  
When it is set to ENABLE, SRQ=TRUE is output at the end of sampling.  
**Note:** Service request is in DISABLE when the power supply is ON.

**Structure** SRQ = ENABLE/DISABLE

SRQ = : Command to set a service request.

ENABLE/DISABLE : Designates permission with “ENABLE”.  
Designates prohibition with “DISABLE”.

**Transmission**

Sets the service request permission.

SRQ=ENABLE C<sub>R</sub>L<sub>F</sub>

### 2.2.24 SRQ? (Readout of Service Request Status)

**Function** To read out the status of service request.

**Structure** SRQ?

**Transmission**

SRQ?C<sub>R</sub>L<sub>F</sub>

**Reply**

SRQ=ENABLE C<sub>R</sub>L<sub>F</sub>

①                      ②

① Shows the output of service request data. (Data length = 3)

② Shows the status.

“ENABLE” shows permission.

“DISABLE” shows prohibition.

**2.2.25 TC= (Setting of T.C Standard Temperature, Temperature Coefficient)**

**Function** To set the T.C referential temperature, temperature coefficient.

**Structure** TC =  'C,  ppm

TC = : Command to set the T.C referential temperature, temperature coefficient.

: Designates the referential temperature.  
Adjustable range 0.0~149.9°C.

: Designates the temperature coefficient (  $\alpha$  ).  
Adjustable range 1000~4999.

**Transmission**

Set the referential temperature and temperature coefficient respectively to 25.0°C, 0.00393.

TC=25.0°C , 3930ppm

**2.2.26 TC? (Readout of T.C Standard Temperature, Temperature Coefficient)**

**Function** To read the data of T.C referential temperature, temperature coefficient.

**Structure** TC?

**Transmission**

TC?

**Reply**

TC=025.0 °C , 3930ppm

①      ②      ③

①Shows the output value of T.C referential temperature (Data length = 2).

②Shows the referential temperature data (Data length = 7)

③Shows the temperature coefficient data (Data length = 7)

### 2.2.27 ZEROADJ= (Setting of Zero Adjustment)

**Function** To set a zero adjustment.  
Zero adjustment is the function to memorize the measured value at the time of receiving ZEROADJ=ON, as zero set value, and to display the value obtained by reducing the zero set value from the measured value by the time when received ZEROADJ=OFF.

**Structure** ZEROADJ = ON/OFF

ZEROADJ = : Command to set a zero adjustment,

ON/OFF : Designates to be valid with "ON".  
Designates release with "OFF".

**Transmission**

Set the zero adjustment to ON.

ZEROADJ=ON  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

### 2.2.28 ZEROADJ? (Readout of Zero Adjustment Status)

**Function** To read the status of zero adjustment.

**Structure** ZEROADJ?

**Transmission**

ZEROADJ? $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

**Reply**

ZEROADJ=OFF  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

① ②

①Shows the output of zero adjustment status (Data length = 7).

②Shows the status of zero adjustment.

### 3. SERVICE REQUEST

After receiving SRQ=ENABLE and at the finish of measurement sampling, 3565 makes the service request to SRQ=True (makes the bit6 of status byte to 1) and makes a service request to a controller.

The controller receiving the service request can know the device which transmitted the service request by reading the status byte with serial pole.

SRQ=True is cleared by the controller's serial pole.

#### 3.1 Status Byte

Format of the status byte to transmit in serial pole is as table below:

bit	7	6	5	4	3	2	1	0
	0	SRQ	HOLD	0	0	HIGH	GOOD	LOW

1. SRQ (bit6) : When the output of service requested is permitted, it outputs True ("1") at the when 3565 finishes the measurement.  
SRQ=True is released by the serial pole from the host.  
When the power supply is ON, or when the output of service request is prohibited, FALSE ("0") is always output.
2. HOLD (bit5) : When 3565 is in hold action and the sampling is stopped, it becomes "1".  
When 3565 is in measuring action, it becomes "0".
3. HIGH (bit2) : When 3565 is in HI judgement output, it becomes "1".
4. GOOD (bit1) : When 3565 is in GO judgement output, it becomes "1".
5. LOW (bit0) : When 3565 is in LO judgement output, it becomes "1".

**Note 1)** bit7, bit4 and bit3 are fixed at "0".

**Note 2)** When the judgement is reset by judgement reset control,  
HIGH (bit2), GOOD (bit1) and LOW (bit0) become "0".

### 4. DEVICE CLEAR FUNCTION

When 3565 received the device clear (DCL, SDC), it initiates the system and becomes in status of power supply ON.

**Note:** After the device clear, each parameter of 3565 needs to be set again.

When ONLINE is made by the front panel key, the online becomes off after the device clear. Make the online again with the key.

(In case that the ONLINE is made by with dip switch on GP-IB board, the status is continuously be online even after the device clear.)

### 5. DEVICE TRIGGER FUNCTION

When 3565 received the device trigger (GET) during the hold status, it makes one shot sampling.

---

Instruction Manual  
Interface of RS-232C

**MODEL 5811-05**  
(for Model 3565)

---

I-01777

# Contents

	Page
<b>1.Specifications</b> .....	3
<b>2.Connection</b> .....	3
2.1 Connector and signal .....	3
2.2 Xon/Xoff control .....	3
2.3 Connection cable .....	4
2.4 Setting of communication .....	4
2.5 ONLINE switch .....	4
<b>3.Explanation of communication</b> .....	5
<b>4.Explanation of command</b> .....	6
4.1 ●Program data .....	6
4.2 ●Detail of program data .....	7
4.2.1 BUZZ= (setting of buzzer) .....	7
4.2.2 BUZZ? (read-out of buzzer data) .....	7
4.2.3 MODE= (changeover of mode) .....	8
4.2.4 MEM=CALL (call-up of memory) .....	8
4.2.5 MEM [No.]? (read-out of memory setting data) .....	8
4.2.6 MEM= (setting of memory data) .....	9
4.2.7 COMP=, (setting of comparator) .....	10
4.2.8 COMP? (read-out of comparator data) .....	10
4.2.9 DATA? (read-out of measurement data) .....	11
4.2.10 FUNCTION= (measuring function) .....	12
4.2.11 FUNC? (read-out of function data) .....	12
4.2.12 HOLD= (setting of hold) .....	13
4.2.13 HOLD? (read-out of hold status) .....	13
4.2.14 RANGE= (setting of measuring range) .....	14
4.2.15 RANGE? (read-out of measuring range) .....	14
4.2.16 RATIOSTD= (setting of standard ratio value) .....	15
4.2.17 RATIOSTD? (read-out of standard ratio value) .....	15
4.2.18 RST= (judgement reset) .....	16
4.2.19 RST? (read-out of judgement reset status) .....	16
4.2.20 SAMPLING= (setting of sampling rate) .....	17
4.2.21 SAMPLING? (read-out of sampling rate) .....	17
4.2.22 TC= (Setting of T.C reference temperature and temperature coefficient) .....	18
4.2.23 TC? (Read out of reference temperature and temperature coefficient data) .....	18
4.2.24 ZEROADJ= (setting of zero adjustment) .....	19
4.2.25 ZEROADJ? (read-out of zero adjustment) .....	19



## 1. Specifications


**Table 1.1**

Transmission system	Start-stop synchronous duplex transmission
Transmission speed	9600, 4800, 2400bps (Set to 9600bps at delivery from factory)
Data bit length	8 bit
Stop bit	1 bit
Parity bit	Nil, even number, odd number (Set to Nil at delivery from factory)
Delimiter	LF (0AH)
Xon/Xoff	Controllable (Xon at delivery from factory)
Connector	Sub-D 9 pin (male)


## 2. Connection

### 2.1 ●Connector and signal

Meter connector D-sub9pin



Attached connector: D-sub9pin plug type



XM2D-0901 (OMRON)


Pin No.	Meter signal JIS (RS-232C)	Direction	Name
①			Not in use
②	RD (RXD)	Input	Receiving data
③	SD (TXD)	Output	Transmission data
④			Not in use
⑤	SG (GND)		Ground for signal
⑥			Not in use
⑦	RS (RTS)	Output	Request for transmission
⑧	CS (CTS)	Input	Transmittable
⑨			Not in use

### 2.2 ●Xon/Xoff control

Soft handshake: The transmission is stopped when Xoff is received and re-started when Xon is received.  
(Xon: 11H (ASCII), Xoff: 13H (ASCII))

## 2.3 ●Connection cable


No hardware handshake



## 2.4 ●Setting of communication

Setting of the communication speed and parity bit can be done by the dip switch on the rear panel.

Arrangement of dip switch on the rear panel.



Setting of communication speed

Set the speed with the dip switch 1, 2 and 3.

Communication speed	1	2	3
2400bps	○	×	×
4800bps	×	○	×
9600bps	×	×	○

Set the switch marked ○ to ON

Set the switch marked × to OFF

Setting of parity bit

Set the parity with the dip switch 4 and 5.

Parity bit	4	5
Even number	○	×
Odd number	×	○
Nil	×	×

Set the switch marked ○ to ON

Set the switch marked × to OFF

**Note:** Make the setting of the dip switch with the power supply switched OFF.

## 2.5 ●ONLINE switch

By setting the dip switch No.8 on the rear panel to ON side, the ONLINE on the front panel is lit up, and it is enabled to do a remote control by RS-232C and to read-out the data setting.

The control functions in ONLINE are as follows.


● Setting of each setting parameter is possible.

**Note:**

- In the ONLINE status, the key operation from the front panel is not allowed.
- Read-out of the measurement data and working status is possible both in OFFLINE and ONLINE.

### 3. Explanation of communication

---



#### Response frame:

When the effective setting command is received, the content of setting is returned.

When the effective output command is received, the designated data is output.

When the ineffective command is received, the "Command Error" is returned.

Example: In case of effective command: FUNCTION=OHM  $\text{C}_R \text{L}_F$ ,

Response: FUNCTION=OHM  $\text{C}_R \text{L}_F$

In case of ineffective command: FUNCTION=MACHIGAI  $\text{C}_R \text{L}_F$ ,

Response: Command Error  $\text{C}_R \text{L}_F$

## 4. Explanation of command

### 4.1 ●Program data

JIS punctuation code is used for the command data.

Example:

RANGE=30kOHM C<sub>R</sub> L<sub>F</sub>

Command      Delimiter

1. Command      Command to control the 3565.
2. Delimiter      Code (delimiter) to inform the 3565 of the finish of transmission data block.  
L<sub>F</sub> judged as delimiter when received the (OAH).

**Table of character code**

	0	1	2	3	4	5	6	7
0			SP	0	@	P	`	p
1			!	1	A	Q	a	q
2			”	2	B	R	b	r
3			#	3	C	S	c	s
4			\$	4	D	T	d	t
5			%	5	E	U	e	u
6			&	6	F	V	f	v
7			'	7	G	W	g	w
8			(	8	H	X	h	x
9			)	9	I	Y	i	y
A			•	:	J	Z	j	z
B			+	;	K	[	k	{
C			,	<	L	¥	l	
D			-	=	M	]	m	}
E			.	>	N	^	n	~
F			/	?	O	_	o	

Blank code is undefined.

---

## 4.2 ●Detail of program data ---

### 4.2.1 BUZZ= (setting of buzzer)

**Function** Make the setting of buzzer for OFF, GOOD, NG, HI and LO.

**Structure** BUZZ= OFF/GOOD/NG/HI/LO, Data

BUZZ= : Buzzer setting command

OFF/GOOD/NG/HI/LO :

“OFF” designates the buzzer OFF.

“GOOD” designates the buzzer at GOOD.

“NG” designates the buzzer at NG.

“HI” designates the buzzer at HIGT.

“LO” designates the buzzer at LOW.

**Note:** Either one of the buzzer setting is possible.

Data : Designates the buzzer sound volume.  
Sound volume can be set in 9 steps “01” ~ “10”.

**Note:** When the setting is buzzer OFF, the designation for buzzer sound volume is disregarded.

**Transmission**

Set GOOD buzzer sound level to 3.

BUZZ=GOOD, 03 C<sub>R</sub> L<sub>F</sub>

### 4.2.2 BUZZ? (read-out of buzzer data)

**Function** The mode and the sound volume of buzzer are read out.

**Structure** BUZZ?

**Transmission**

BUZZ? C<sub>R</sub> L<sub>F</sub>

**Response**

BUZZ=GOOD, 03 C<sub>R</sub> L<sub>F</sub>

①      ②

① The data of buzzer mode. (data length = 4)

② The sound volume data 01 ~ 10. (data length = 2)

#### 4.2.3 MODE= (changeover of mode)

**Function** Changeover of memory mode, manual mode.

**Structure** MODE=**Mode**

MODE= : Mode changeover command

**Mode** : “MEMORY” designates the memory mode.  
“MANUAL” designates the manual mode.

**Transmission**

Designate to the memory mode.

MODE=MEMORY **C<sub>R</sub>** **L<sub>F</sub>**

#### 4.2.4 MEM=CALL (call-up of memory)

**Function** The memory designated by the No. is called up.  
**Note:** Make the setting after changing to the memory mode.

**Structure** MEM=CALL **No.**

MEM= : Memory number setting command.

**No.** : Designate the memory “01” ~ “30”.

**Transmission**

Designates to the memory No.01 and works afterwards as the memory No.01.

MEM=CALL01 **C<sub>R</sub>** **L<sub>F</sub>**

#### 4.2.5 MEM **No.**? (read-out of memory setting data)

**Function** Read out the memory data designated by the No.  
**Note:** Make the setting after changing to the memory mode.

**Structure** MEM **No.**?

**No.** : Designate the memory “01” ~ “30”.

**Transmission**

MEM01? **C<sub>R</sub>** **L<sub>F</sub>**

**Response**

MEM=01, OHM\_ \_ \_ \_ , 300mOHM, H35. 000\_OHM, L100. 00\_OHM **C<sub>R</sub>** **L<sub>F</sub>**  
① ② ③ ④ ⑤

- ① Shows the memory number (data length = 4).
- ② Shows the resistance measurement function (data length = 10).
- ③ Shows the resistance measurement range (data length = 7).
- ④ Shows the HI data of memory (data length = 7).
- ⑤ Shows the LO data of memory (data length = 7).

#### 4.2.6 MEM= (setting of memory data)

Function	Set the memory data. Make the setting after changing to the memory mode.
Structure	MEM= <input type="text" value="No."/> , <input type="text" value="FUNC"/> , <input type="text" value="RANGE"/> , H <input type="text" value="HI SET"/> , L <input type="text" value="LO SET"/>
	MEM= : Data setting command of the memory.
	<input type="text" value="No."/> : Designate the memory number "01" ~ "30".
	<input type="text" value="FUNC"/> : Function table "OHM", "OHM-RATIO", "TC-RATIO", "TC".
	<input type="text" value="RANGE"/> : Designates either one of the range "300mOHM", "3OHM", "300OHM", "3000OHM", "3kOHM", "30kOHM", "300kOHM".
	<input type="text" value="HI SET"/> : High limit value data of the comparator. (Adjustable range of numeral: 0~35000)
	<input type="text" value="LO SET"/> : Low limit value data of the comparator. (Adjustable range of numeral: 0~35000)

**Note-1:**  and  are to be set adding the unit and decimal point.

Example of setting: 35.000kOHM

**Note-2:** When the FUNC is RATIO, HI SET: Standard value,  
LO SET: Deviation  $\Delta$  are to be set.

Example of setting: H100.000OHM, L10.0%

**Note-3:** The constant of temperature compensation is set by "TC=" (4.2.22)

#### Transmission

● When the function is set to temperature compensation.

For the memory NO.1, respectively set FUNC to OHM, RANGE to 3k $\Omega$ , HI SET to 2.0000k $\Omega$  and LO SET to 1.5000k $\Omega$ .

MEM=01, OHM, 3kOHM, H2.0000kOHM, L1.5000kOHM

● When the function is set to ratio display.

For the memory NO.10, respectively set FUNC to OHM-RATIO, RANGE to 300m $\Omega$ , REF to 200m $\Omega$  and  $\Delta$  to 10.0%.

MEM=10, OHM-RATIO, 300mOHM, H200.00mOHM, L010.0%

#### 4.2.7 COMP= (setting of comparator)

##### Function

Set the high and low limit value and the unit of the comparator.

**Note:** It can not be set when the measurement function is RATIO (ratio display) and TE (temperature conversion).

##### Structure

COMP=H [HI SET], L [LO SET]

COMP= : Comparator setting command

[HI SET] : High limit set value of the comparator  
(Adjustable range of numeral 0~35000)

[LO SET] : Low limit set value of the comparator  
(Adjustable range of numeral 0~35000)

**Note-1:** HI SET and LO SET are to be set adding the unit and decimal point.

Example of setting: 35.000kOHM

**Note-2:** Adjust the unit and decimal point of HI SET and LO SET to the same.

##### Transmission

Set the HI SET of to 2.0000k $\Omega$  and the LO SET to 1.5000k $\Omega$ .

COMP=H2.0000kOHM, L1.5000kOHM [C]<sub>R</sub>[L]<sub>F</sub>

#### 4.2.8 COMP? (read-out of comparator data)

##### Function

Read out the high and low limit value of the comparator.

**Note:** It can not be read out when the measurement function is RATIO (ratio display) and TE (temperature conversion).

##### Structure

COMP?

##### Transmission

COMP? [C]<sub>R</sub>[L]<sub>F</sub>

##### Response

COMP=H300.00kOHM, L100.00kOHM [C]<sub>R</sub>[L]<sub>F</sub>

①

②

③

① Shows the data output of comparator. (data length = 4)

② Shows the HI data of the comparator. (data length = 10)

③ Shows the LO data of the comparator. (data length = 10)



---

#### 4.2.9 DATA? (read-out of measurement data)

**Function** Designate the data to read out to the measurement data.

**Structure** DATA?

DATA? : Measurement data output command

**Transmission**

DATA?  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

**Response**

1. Resistance measurement.

OHM=199.99kOHM, JUDGE=HIGH LOW  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

2. Temperature measurement.

TEMP=0100.0° C  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

3. Ratio measurement.

RATIO=0123.4%, Rs=1.0000\_OHM, Rx=1.2345\_OHM, JUDGE=GOOD  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

4. Temperature compensation measurement.

T.C=127.76mOHM, R=130.02mOHM, TEMP=0024.5° C, JUDGE=GOOD  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

5. Temperature conversion T1 measurement.

R1=130.66kOHM, T1=0024.5° C, JUDGE=GOOD  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

6. Temperature conversion T2 measurement

R2=130.66kOHM, T2=0024.5° C, JUDGE=NULL  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

7. Temperature conversion T.E calculation

T.E=0014.3° C, R1=130.66kOHM, T1=0024.5° C, R2=123.45kOHM,  
T2=0024.5° C, JUDGE=NULL  $\begin{matrix} \text{C}_R \\ \text{L}_F \end{matrix}$

**Note:** JUDGE output

At GO	: JUDGE=GOOD
At HI	: JUDGE=HIGH
At LO	: JUDGE=LOW
At No judgement output	: JUDGE=NULL
At Err1, Err2	: JUDGE=HIGH LOW

#### 4.2.10 FUNCTION= (measuring function)

**Function** Designate the measuring function.

**Note:** Change over from temperature measurement to other function than resistance measurement is not possible.

**Structure** FUNCTION=**Function code**

FUNCTION= : Measuring function setting command

**Function** : Refer to the table below.

Function code	measuring function
OHM	Resistance measurement
TEMP	Temperature measurement
OHM-RATIO	Ratio measurement (resistance)
TC-RATIO	Ratio measurement (temperature compensation)
TC	Temperature compensation measurement
TE-CLEAR	Data clearance of temperature conversion measurement
TE	Temperature conversion (T.E) calculation
T1	Temperature conversion (T1) measurement
T2	Temperature conversion (T2) measurement

**Transmission**

Set the measuring function to the resistance measurement.

FUNCTION=OHM  $\text{C}_R$   $\text{L}_F$

#### 4.2.11 FUNC? (read-out of function data)

**Function** Read out the type of measuring function.

**Structure** FUNC?

FUNC? : Measuring function output command

**Transmission**

FUNC?  $\text{C}_R$   $\text{L}_F$

**Response**

FUNCTION=OHM  $\text{C}_R$   $\text{L}_F$

① ②

① Shows the function data output. (data length = 9)

② Shows the measuring function data.

---

#### 4.2.12 HOLD= (setting of hold)

Function	Set the start and cancellation of the hold.
Structure	HOLD= ON/OFF  HOLD= : Hold setting command.  ON/OFF : Stop the sampling and hold the data with “ON”. Designate the cancellation of hold with “OFF”.
Transmission	
	Set the hold to ON.
	HOLD=ON $\overset{C}{R}$ $\overset{L}{F}$

#### 4.2.13 HOLD? (read-out of hold status)

Function	Read out the status of hold.
Structure	HOLD?
Transmission	
	HOLD? $\overset{C}{R}$ $\overset{L}{F}$
Response	
	HOLD=ON_ $\overset{C}{R}$ $\overset{L}{F}$ ① ②
	① Shows the hold data output. (data length = 4) ② Shows the status data of the hold.

#### 4.2.14 RANGE= (setting of measuring range)

##### Function

Set the range of resistance measurement.

**Note:** No setting is possible in the temperature measurement.

##### Structure

RANGE= Range

RANGE= : Measuring range setting command

Range : For the resistance measurement, set the range among 300mΩ ~ 300kΩ.

To make the auto-range, set AUTO.

**Table 4.1**

Range code	Measuring range
300mOHM	300mΩ
3OHM	3Ω
30OHM	30Ω
300OHM	300Ω
3kOHM	3kΩ
30kOHM	30kΩ
300kOHM	300kΩ
AUTO	Auto-range

##### Transmission

Set the resistance measurement range to 30Ω.

RANGE=30OHM C<sub>R</sub>L<sub>F</sub>

#### 4.2.15 RANGE? (read-out of measuring range)

##### Function

Read out the setting condition of the measuring range.

##### Structure

RANGE?

##### Transmission

RANGE? C<sub>R</sub>L<sub>F</sub>

##### Response

RANGE=30kOHM C<sub>R</sub>L<sub>F</sub>

①      ②

- ① Shows the range data output .(data length = 4)
- ② Shows the data of setting condition of the range.

---

#### 4.2.16 RATIOSTD= (setting of standard ratio value)

##### Function

Set the standard value and deviation of the ratio display.

**Note:** The setting is not possible when the measuring function is other than the ratio display function.

##### Structure

RATIOSTD=[REF], [±Δ]

RATIOSTD : Setting command of the ratio standard value.

[REF]

: Standard resistance value.

[±Δ]

: ±Δ deviation data (00.0~100.0%)

##### Transmission

Set the 10.000kΩ to the standard resistance value, and 20.0% to the deviation Δ%.

RATIOSTD=10.00kOHM, 20.0% [C<sub>R</sub>] [L<sub>F</sub>]

#### 4.2.17 RATIOSTD? (read-out of standard ratio value)

##### Function

Read the data of ratio standard value.

##### Structure

RATIOSTD?

##### Transmission

RATIOSTD? [C<sub>R</sub>] [L<sub>F</sub>]

##### Response

RATIOSTD=100.00kOHM, 020.0% [C<sub>R</sub>] [L<sub>F</sub>]

①

②

③

① Shows the data output of the ratio standard.

② Shows the data of standard value. (data length = 10)

③ Shows the deviation data Δ%. (data length = 6)

---

#### 4.2.18 RST= (judgement reset)

Function	Make ON/OFF of reset for the comparator judgement. (Reset the comparator output and turn OFF the ratio display.)
Structure	RST= <span>ON/OFF</span>  RST=           : Setting command of the judgement reset.  <span>ON/OFF</span> : Designate the reset of judgement output with “ON”. Designate the cancellation of reset with “OFF”.

##### Transmission

Reset the comparator judgement output.

RST=ON C<sub>R</sub> L<sub>F</sub>

- One sampling hold  
While the 3565 is in hold status, and when the reset is made ON and afterward turned OFF, one sampling hold can be done.

#### 4.2.19 RST? (read-out of judgement reset status)

Function	Read out the status of comparator judgement reset.
Structure	RST?

##### Transmission

RST? C<sub>R</sub> L<sub>F</sub>

##### Response

RST=OFF C<sub>R</sub> L<sub>F</sub>

①   ②

- ① Shows the data output of reset.
- ② Shows the status of reset.

#### 4.2.20 SAMPLING= (setting of sampling rate)

##### Function

Set the sampling rate.

The temperature measurement is at the fixed sampling rate 4 times/sec. and it can not be changed.

##### Structure

SAMPLING= SLOW/MEDIUM/FAST

SAMPLING= : Setting command of the sampling rate.

SLOW/MEDIUM/FAST :

SLOW : 4 times/sec.  
MEDIUM : 20 times/sec.  
FAST : 100 times/sec.

	sampling rate
SLOW	Low speed (4 times/sec)
MEDIUM	Inside velocity (20 times/sec)
FAST	High speed (100 times/sec)

##### Transmission

Set the measuring sampling rate to low speed (4 times/sec).

SAMPLING=SLOW  $\text{C}_R \text{L}_F$

#### 4.2.21 SAMPLING? (read-out of sampling rate)

##### Function

Read out the status of sampling rate.

##### Structure

SAMPLING?

##### Transmission

SAMPLING?  $\text{C}_R \text{L}_F$

##### Response

SAMPLING=SLOW  $\text{C}_R \text{L}_F$   
① ②

- ① Shows the sampling data output.  
② Shows the status.

---

#### 4.2.22 TC= (Setting of T.C reference temperature and temperature coefficient)

Function	Set the reference temperature and temperature coefficient.
Structure	TC= <input type="text"/> temperature data ' C, <input type="text"/> $\alpha$ data ppm TC= : Setting command of T.C reference temperature and temperature coefficient. <input type="text"/> Temperature data : Designates the reference temperature. Adjustable range 0.0~149.9°C. <input type="text"/> $\alpha$ data : Designates the temperature coefficient ( $\alpha$ ) Adjustable range 1000~4999

##### Transmission

When 25.0°C is set to reference temperature and 0.00393 to temperature coefficient.

TC=25.0' C, 3930ppm

#### 4.2.23 TC? (Read out of reference temperature and temperature coefficient data)

Function	Read out the reference temperature and temperature coefficient data
Structure	TC?
Transmission	TC? <input type="text"/> <input type="text"/>
Response	

TC=025.0' C, 3930ppm

①      ②      ③

- ① Shows the T.C reference temperature output value. (data length = 2)
- ② Reference temperature data (data length = 7)
- ③ Temperature coefficient data (data length = 7)



#### 4.2.24 ZEROADJ= (setting of zero adjustment)

**Function**      Make the setting of zero adjustment.  
The zero adjustment action is that the measured value at the moment when the ZEROADJ=ON is received is memorized as the zero set value, and the value deducted the zero set value from the measured value is displayed and output until the ZEROADJ=OFF is received.

**Structure**      ZEROADJ=

ZEROADJ=    : Zero adjustment setting command.

   : Designate the effect with “ON”.  
                         Designate the cancellation with “OFF”.

**Transmission**

Set the zero adjustment to ON.

ZEROADJ=ON

#### 4.2.25 ZEROADJ? (read-out of zero adjustment)

**Function**      Read out the status of zero adjustment.

**Structure**      ZEROADJ?

**Transmission**

ZEROADJ?

**Response**

ZEROADJ=OFF

①      ②

- ① Shows the status of zero adjustment output. (data length = 7)  
② Shows the status of zero adjustment.

#### Contact Information

Name : Tsuruga Electric Corporation  
Address : 1-3-23 Minami-Sumiyoshi, Sumiyoshi-ku, Osaka-shi  
558-0041 Japan