

DECT-3

Digital Earth Clamp Tester With Leakage Current Measurement

Features:

- RS 232 Interface for monitoring, uploading, analyzing & printing of data
- Memory Storage capability of 99 records
- \odot Extended resistance range upto 1200 Ω
- AC Leakage current measurement up to 20A
- Alarm setting feature with selection range available for resistance and current
- Improved Jaw Opening & Closing
- Fast self test & Calibration
- Soft touch keys
- Rugged casing and easy to use

General Specifications:

mm	
4 digit LCD , 47 mm X 28.5 mm	
0.01Ω to 1200Ω	
0 to 20 A	
99 records	
RS 232 for uploading the stored data and analysing at later time	
0.5 Second	
> 1 KHz	
Beep sound, Flashing 4 symbol, 'AL' key to turn on-off & setting the sound & Light alarm	
< 40 A/m	
< 1V/m	
attery)	
approx 5 minutes	
Working Temperature:0°C to 50°C Relative Humidity: 10% to 90%	
65mm X 32mm	
285mm x 85mm x 56mm	
1160 gms	

Technical Specifications:

Mode	Range	Resolution	Accuracy
Resistance	0.010-0.099 Ω	0.001 Ω	$\pm (1\% + 0.01\Omega)$
	0.10-0.99 Ω	0.01 Ω	$\pm (1\% + 0.01\Omega)$
	1.0-49.9 Ω	0.1 Ω	$\pm (1\% + 0.1\Omega)$
	50.0-99.5 Ω	0.5 Ω	$\pm (5\% + 5\Omega)$
	100-199 Ω	1 Ω	$\pm (5\% + 5\Omega)$
	200-395 Ω	5Ω	$\pm (10\% + 10\Omega)$
	400-590 Ω	10 Ω	$\pm (10\% + 25\Omega)$
	600-880 Ω	20 Ω	$\pm (20\% + 30\Omega)$
	900-1200 Ω	30 Ω	$\pm (25\% + 30\Omega)$
Current	0-9 mA	0.05 mA	Unspecified
	10-99 mA	0.1 mA	± (2.5% + 20mA)
	100-300 mA	1 mA	± (2.5% + 20mA)
	0.30-2.99 A	0.01 A	± (2.5% + 0.15mA)
	3.0-9.9 A	0.1 A	± (2.5% + 0.5mA)
	10.0-20.0 A	0.1 A	± (2.5% + 1A)

Applications:

- Measures Earth Resistance of the electrical ground rod and grid.
- Measures AC leakage current of transformer neutral.
- Used to test the quality of the grounding without disconnecting the ground rod under test.
- Conduct field surveys fast and effectively and retrieves and analyzes the readings for later reference
- Used to test the telecommunication Tower's grounding.
- Used in finding the earth fault such as discontinuation or loose contact of earthing strips or cables.
- To find the resistance of earth pit.

Standard Accessories:

- Carrying Case
- Standard Loop Resistance of 5.1Ω
- Instruction Manual
- PC Software CD
- Calibration Certificate



NOTES

1. The Instrument is accompanied with Test & calibration sheet. 2. Test facilities can be provided at the factory with the available test set-ups only. 3. The Company's policy is continuous improvement of its product, we therefore reserve the Right of any deviation from illustration or specifications without notices. 4. Accuracy Specified for temperature range of $25^{\circ}\text{C} \pm 5^{\circ}\text{C} \& 55\%\text{RH} \pm 10\%$



The Motwane Manufacturing Company Pvt. Ltd.

Pvt. Ltd.

L

SO 9001 REGISTERED

REGD. OFF. & FACTORY: Gyan Baug, Motwane Road, Nashik Road-422101

Tel.: +91 - 253 - 2463752 / 53 Fax.:+91 - 253 - 2463197 e-mail: sales@motwane.com Toll Free No.:18002337766

MUMBAI: 223-224, MIDAS, Sahar Plaza, Andheri - Kurla road, J. B. Nagar, Andheri (E), Mumbai - 400059

TEL: +91-22-40155585 / 6 / 7 FAX: +91-22-40155588 e-mail: mumbai@motwane.com

DELHI: 2 D, 2nd Floor, Vandana Building, 11, Tolstoy Marg, Cannaught Place, New Delhi - 110 001

Tel.: +91 - 11 - 41522 105 Fax.: +91 - 11 - 41522 106 e-mail: delhi@motwane.com

BANGALORE: #8 / 12, 3rd Floor, Honnam Complex, South Cross Road, Basavanagudi, Bangalore - 560 004.

Tel.: +91 - 80 - 26611323 Fax.:+91 - 80 - 26621186. e-mail: bangalore@motwane.com

KOLKATA OFFICE: Eden Terrace, 10, Tarak Datta Road, Near Beck Bagan Methai, Kolkata – 700019.

Tele Fax: +91-33-22832436. FCT Land Line: +91-9007791374. E-mail:Kolkata@motwane.com

To make enquiry please visit www.motwane.com and click 'Make an enquiry'.

Represented by