MXG X-Series Signal Generators N5181B Analog and N5182B Vector

This configuration guide will help you determine which performance options, software applications, accessories, and services to include with your new MXG or to add as upgrades to an existing MXG.





GURATION

GUIDE

Configure Your MXG X-Series Signal Generator

This step-by-step process will help you configure your MXG signal generator. Tailor the performance to meet your requirements. For detailed specifications, refer to the MXG signal generator data sheet (5991-0038EN).

N5181B MXG X-Series RF Analog Signal Generator

Configure your new MXG analog signal generator

Step 1. Select maximum frequency range (required option; frequency range not upgradeable)				
Description	Option number	Additional information		
Frequency range from 9 kHz to 3 GHz	N5181B-503	Not compatible with 506		
Frequency range from 9 kHz to 6 GHz	N5181B-506	Not compatible with 503		

Step 2. Choose connector configuration		
Description	Option number	Additional information
Move all connectors to rear panel	N5181B-1EM	Not upgradable

Step 3. Choose performance enhancement option		A dell'Alternation della de
Description	Option number	Additional information
AM, FM, phase modulation	N5181B-UNT	
Low phase noise	N5181B-UNX	Not compatible with UNY, not upgradable
Enhanced low phase noise	N5181B-UNY	Not compatible with UNX, not upgradable
Fast switching	N5181B-UNZ	
Narrow pulse modulation	N5181B-UNW	
Multifunction generator	N5181B-303	
Instrument security and removable memory card	N5181B-006	
No internal non-volatile memory	N5181B-SD0	Requires firmware B.01.80 or newer
High output power	N5181B-1EA	
Low specified power (<-110 dBm)	N5181B-1EQ	
Flexible reference input (1 to 50 MHz)	N5181B-1ER	
Expanded license key upgradability	N5181B-099	Option 099 is recommended for anyone considering future upgrades. Option 099 simplifies the upgrade process by enabling upgrades via a license key for Options 1EA, 1EQ, and UNZ. Without Option 099, upgrades for these options require purchase and installation of hardware in a field retrofit kit. For more information, visit www.keysight.com/find/SSupgrades.

Step 4. Choose accessory and documentation options		
Description	Option number	
Rack slide kit	1CR112A	
Front handle kit	1CN106A	
Rack mount flange kit	1CM110A	
Rack mount flange kit with front handles	1CP104A	
Front panel cover	N5181B-CVR	
Hard transit case	N5181B-AXT	
CD-ROM containing English documentation set	N5181B-CD1	

Step 5. Choose embedded software

Note: The following software can be added at purchase or as an upgrade. F	For more information on licenses, go to N	www.keysight.com/find/SS_licensing
Description	Option number	Hardware requirements
Avionics (VOR/ILS)	N5180302B	
Pulse train generator	N5180320B	UNW

Step 6. Choose calibration options

- · · · · · · · · · · · · · · · · · · ·	
Description	Option number
MXG analog ANSI Z540-1-1994 calibration	N5181B-A6J
MXG analog Keysight Cal + uncertainties + guardbanding (accredited cal)	N5181B-AMG
Commercial calibration certificate with test data	N5181B-UK6
Calibration Assurance Plan, Return-to-Keysight, 5 Years	R-50C-011-5
Calibration Assurance Plan, Return-to-Keysight, 7 Years	R-50C-011-7
Calibration Assurance Plan, Return-to-Keysight, 10 Years	R-50C-011-10

Step 7. Choose startup assistance service options

Description	Option number
Remote scheduled assistance 1- 999 hours	PS-S10
Daily productivity assistance	PS-S20
Signal generator and source basics; half-day, maximum of eight students on site	PS-T10-ASG
Custom services to be qualified by Keysight	PS-X10

Upgrade your Existing MXG Analog Signal Generator

Fast license-key upgrades for options that do not require additional hardware:

- 1. Place an order for the upgrade with Keysight and request to receive the software entitlement certificate through email
- 2. Redeem the certificate through the Web by following the instructions on the certificate
- 3. Install the license file using Keysight License Manager
- 4. Begin using the new capability

Installation, calibration, and verification information is available at: www.keysight.com/find/mxg_upgrades

You can upgrade!

Options can be added after your initial purchase. Most X-Series options are license-key upgradeable.



Description	Upgrade number	Requirements	Additional information
Instrument security and removable memory card	N5181BU-006	None	Hardware and license key upgrade
No internal non-volatile memory	N5181BU-SD0	None	Customer installable - software, license key
			Requires firmware B.01.80 or newer
Expanded license key upgradability	N5181BU-099	None	Hardware and license key upgrade
High output power	N5181BU-1EA	099	Customer installable - software, license key
Low specified power (<-110 dBm)	N5181BU-1EQ	099	Customer installable - software, license key
Flexible reference input (1 to 50 MHz)	N5181BU-1ER	None	Customer installable - software, license key
Multifunction generator	N5181BU-303	None	Customer installable - software, license key
Avionics (VOR/ILS)	N5180302B	None	Customer installable - software, license key
Pulse train generator	N5180320B	UNW	Customer installable - software, license key
AM, FM, phase modulation	N5181BU-UNT	None	Customer installable - software, license key
Narrow pulse modulation	N5181BU-UNW	None	Customer installable - software, license key
Fast switching	N5181BU-UNZ	099	Customer installable - software, license key
Rack slide kit	1CR112A	None	Hardware
Front handle kit	1CN106A	None	Hardware
Rack mount flange kit	1CM110A	None	Hardware
Rack mount flange kit with front handles	1CP104A	None	Hardware
Front panel cover	N5180-40019	None	Hardware

N5182B MXG X-Series RF Vector Signal Generator

Configure your new MXG vector signal generator

Step 1. Select maximum frequency range (required option; frequency range not upgradeable)			
Description	Option number	Additional information	
Frequency range from 9 kHz to 3 GHz	N5182B-503	Not compatible with 506	
Frequency range from 9 kHz to 6 GHz	N5182B-506	Not compatible with 503	
Frequency range from 9 kHz to 7.2 GHz	N5182B-FRQ	Requires 506 and N5182BX07 Frequency Extender ¹	

1. The N5182BX07 Frequency Extender is orderable separately. Refer to the N5182BX07 configuration guide for more information

Step 2. Choose connector configuration		
Description	Option number	Additional information
Move all connectors to rear panel	N5182B-1EM	Not upgradable
Differential I/Q outputs	N5182B-1EL	

Step 3. Choose performance enhancement options		
Description	Option number	Additional information
AM, FM, phase modulation	N5182B-UNT	
Enhanced dynamic range	N5182B-UNV	Requires 656
Narrow pulse modulation	N5182B-UNW	
Low phase noise	N5181B-UNX	Not compatible with UNY, not upgradeable
Enhanced low phase noise	N5182B-UNY	Not compatible with UNX, not upgradeable
Fast switching	N5182B-UNZ	
Multifunction generator	N5182B-303	
Instrument security and removable memory card	N5182B-006	
Internal solid-state memory	N5182B-009	
No internal non volatile memory/solid state drive	N5182B-SD0	Not compatible with option 009 and 660
		Requires firmware B.01.80 or newer
High output power	N5182B-1EA	
Low specified power (<-110 dBm)	N5182B-1EQ	
Flexible reference input (1 to 50 MHz)	N5182B-1ER	
LO in/out for phase coherency	N5182B-012	
Expanded license key upgradability	N5182B-099	Option 099 is recommended for anyone considering future upgrades. Option 099 simplifies the upgrade process by enabling upgrades via a license key for Options 1EA, 1EQ, UNV, and UNZ. Without Option 099, upgrades for these options require purchase and installation of hardware in a field retrofit kit. For more information, visit www.keysight.com/find/SSupgrades.

Step 4. Choose baseband generator options

erep in encourance generater optione		
Description	Option number	Additional information
ARB baseband generator (80 MHz RF bandwidth, 32 MSa)	N5182B-656	
Upgrade baseband generator from 80 to 160 MHz RF bandwidth	N5182B-657	Requires 656
Upgrade baseband generator memory from 32 to 512 MSa	N5182B-022	Requires 656
Upgrade baseband generator memory from 32 to 1 GSa	N5182B-023	Requires 656
Upgrade baseband generator with real-time capability	N5182B-660	Requires 656
Digital output connectivity with the N5102A	N5182B-003	Requires 656, not upgradable
Digital input connectivity with the N5102A	N5182B-004	Requires 656, not upgradable

Step 5. Choose Signal Studio and embedded software

Note: The following software can be added at purchase or as an upgrade. To configure Signal Studio applications, refer to the configuration assistant at: www.keysight.com/find/signalstudio. For more information on Signal Studio configuration and licenses, go to www.keysight.com/find/SS_licensing.

Product number	Description	Hardware requirements	Recommended hardware options			
Cellular communications						
N7600B	Signal Studio for W-CDMA/HSPA+ (ARB and real-time)	656 660 for real-time	660, 503, UNV, 403			
N7601B	Signal Studio for cdma2000/1xEV-DO (ARB and real-time)	656 660 for real-time	660, 503, 403, UNV			
N7602B	Signal Studio for GSM/EDGE/Evo (ARB and real-time)	656 660 for real-time	660, 503, 403, UNV, UNZ			
N7612B	Signal Studio for TD-SCDMA/HSDPA	656	503, 403, UNV			
N7624B	Signal Studio for LTE/LTE-Advanced FDD (ARB and real-time)	656 660 for real-time	657, 660, 506, 403, UNV			
N7625B	Signal Studio for LTE/LTE-Advanced TDD (ARB and real-time)	656 660 for real-time	657, 660, 506, 403, UNV			
Wireless connect	ivity					
N7606B	Signal Studio for <i>Bluetooth</i> ®	656	506, 403, UNV			
N7615B	Signal Studio for Mobile WiMAX	656	506, 403, UNV			
N7617B	Signal Studio for WLAN 802.11a/b/g/j/p/n/ac	656	657, 506, 403, UNV			
Audio/video broad	dcasting					
N7623B	Signal Studio for digital video (ARB and real-time)	656 660 for real-time	660, 506, 403, 023, UNV			
N7611B	Signal Studio for broadcast radio	656	506, 403, UNV			
Detection, positio	ning, tracking, and navigation					
N7609B	Signal Studio for Global Navigation Satellite Systems (GNSS) (real-time)	656 660 for real-time	660, 503, 023, 403			
General purpose						
N5180302B	Avionics (VOR/ILS)					
N5180403B	Calibrated AWGN	656				
N5180430B	Multitone and two-tone	656				
N5180431B	Custom digital modulation	656				
N5180432B	Phase noise impairment	656				
N5180UN7B	Internal bit error rate analyzer					
N7622B	Signal Studio toolkit – free utility	656	503, UNV			
N5182B	Waveform license 5-pack 1 to 9 (purchase up to 9 packs for 45 Signal	656	503, UNV			
221-229	Studio waveforms)					
N5182B	Waveform license 50-pack 1 to 10 (purchase up to 10 packs for 500	656	503, UNV			
250-259	Signal Studio waveforms)					
N6171A	MATLAB software		656, 503, UNV			

Step 6. Choose accessory and documentation options

Step 0. Choose accessory and documentation options				
Description	Option number			
Rack slide kit	1CR112A			
Front handle kit	1CN106A			
Rack mount flange kit	1CM110A			
Rack mount flange kit with front handles	1CP104A			
Front panel cover	N5182B-CVR			
Hard transit case	N5182B-AXT			
CD-ROM containing English documentation set	N5182B-CD1			

Step 7. Choose calibration options	
Description	Option number
Keysight Calibration + Uncertainties + Guardbanding (accredited cal)	N5182B-AMG
Commercial calibration certificate with test data	N5182B-UK6
ANSI Z540-1-1994 Calibration	N5182B-A6J
Calibration Assurance Plan, Return-to-Keysight, 5 years	R-50C-011-5
Calibration Assurance Plan, Return-to-Keysight, 7 years	R-50C-011-7
Calibration Assurance Plan, Return-to-Keysight, 10 years	R-50C-011-10

Step 8. Choose startup assistance service options

Description	Option number	Additional information			
Remote scheduled assistance 1- 999 hours	PS-S10				
Daily productivity assistance	PS-S20				
Signal generator and source basics; half-day, maximum of eight students	PS-T10-ASG				
on site					
Custom services to be qualified by Keysight	PS-X10				

Upgrade your Existing MXG Vector Signal Generator

Fast license-key upgrades for options that do not require additional hardware:

- 1. Place an order for the upgrade with Keysight and request to receive the software entitlement certificate through email
- 2. Redeem the certificate through the Web by following the instructions on the certificate
- 3. Install the license file using Keysight License Manager
- 4. Begin using the new capability

Installation, calibration, and verification information is available at: www.keysight.com/find/mxg_upgrades

You can upgrade!

Options can be added after your initial purchase. Most X-Series options are license-key upgradeable.



Description	Upgrade number	Requirements	Additional information
Instrument security and removable memory card	N5182BU-006	None	Hardware and license key upgrade
Internal solid-state memory	N5182BU-009	None	Customer installable – software, license key
No internal non volatile memory/solid state drive	N5182BU-SD0	None	Customer installable - software, license key and hardware
			Requires firmware B.01.80 or newer
			Not compatible with option 009 and 660
LO in/out for phase coherency	N5182BU-012	None	Hardware and license key upgrade
Upgrade baseband generator memory from 32 to 512 MSa	N5182BU-022	656	Customer installable – software, license key
Upgrade baseband generator memory from 32 MSa to 1 GSa	N5182BU-023	656	Customer installable – software, license key
Upgrade baseband generator memory from 512 MSa to 1 GSa	N5182BU-043	022 and 656	Customer installable – software, license key
Expanded license key upgradability	N5182BU-099	None	Hardware and license key upgrade
High output power	N5182BU-1EA	099	Customer installable – software, license key
Differential I/Q outputs	N5182BU-1EL	None	Customer installable – software, license key
Low specified power (<-110 dBm)	N5182BU-1EQ	099	Customer installable – software, license key
Flexible reference input (1 to 50 MHz)	N5182BU-1ER	None	Customer installable – software, license key
5-pack waveform license	N5182BU-221	656	Customer installable – software, license key
50-pack waveform license	N5182BU-250	656	Customer installable – software, license key
Multifunction generator	N5182BU-303	None	Customer installable – software, license key
Avionics (VOR/ILS)	N5180302B	None	Customer installable – software, license key
Pulse train generator	N5180320B	UNW	Customer installable – software, license key
Calibrated AWGN	N5180403B	656	Customer installable – software, license key
Multitone and two-tone	N5180430B	656	Customer installable – software, license key
Custom digital modulation	N5180431B	656	Customer installable – software, license key
Phase noise impairment	N5180432B	656	Customer installable – software, license key
Internal bit error rate analyzer	N5180UN7B	None	Customer installable - software, license key
ARB baseband generator (80 MHz RF bandwidth, 32 MSa)	N5182BU-656	None	Customer installable – software, license key
Upgrade baseband generator from 80 to 160 MHz RF bandwidth	N5182BU-657	656	Customer installable – software, license key
Upgrade baseband generator with real-time capability	N5182BU-660	656	Hardware and license key upgrade
AM, FM, phase modulation	N5182BU-UNT	None	Customer installable – software, license key
Enhanced dynamic range	N5182BU-UNV	099, 656	Customer installable – software, license key
Narrow pulse modulation	N5182BU-UNW	None	Customer installable – software, license key
Fast switching	N5182BU-UNZ	099	Customer installable – software, license key
Rack slide kit	1CR112A	None	Hardware
Front handle kit	1CN106A	None	Hardware
Rack mount flange kit	1CM110A	None	Hardware
Rack mount flange kit with front handles	1CP104A	None	Hardware
Front panel cover	N5180-40019	None	Hardware
Frequency extender connectivity	N5182BU-FRQ	506	Customer installable - software, license key
			Requires N5182BX07 Frequency Extender

Related Literature

Publication name	Publication number
X-Series Signal Generators N5181B/N5171B Analog N5182B/N5172B Vector –Technical Overview	5990-9957EN
MXG X-Series Signal Generators N5181B Analog & N5182B Vector – Data Sheet	5991-0038EN
N5182BX07 Frequency Extender User Guide	N5182-90001

For more information, visit www.keysight.com/find/MXG

Learn more at: www.keysight.com

For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at: www.keysight.com/find/contactus

